

POWER TO INNOVATE. FLEXIBILITY TO ADAPT.

DESIGN, INSTALLATION, OPERATION AND MAINTENANCE MANUAL

FOR

PRE-ENGINEERED AUTOMATIC INDIRECT CARBON DIOXIDE EXTINGUISHER UNITS

Models: 950504 – 5 LB 951004 – 10 LB 952004 – 20 LB (With Dimensional Restrictions)

> July 2016 P/N 800024

Firetrace USA LLC. 8435 N. 90th St, Suite 2 Scottsdale, AZ 85258 USA

Telephone:480-607-1218Fax:480-315-1316

Website: www.firetrace.com Email: <u>firetrace@firetrace.com</u>

TABLE OF CONTENTS

1.0 FORV	VARD	4
1.1 Gei	neral	4
1.2 Saf	ety Precautions	4
2.0 INTR		6
2.1 Car	bon Dioxide Extinguishing Agent	6
2.1.1	Cleanliness	
2.1.2	Physical Properties of Carbon Dioxide	6
2.1.3		
3.0 SYST	EM DESCRIPTION	
3.1 Gei	neral	9
3.1.1	Operating Pressure	
3.1.2	Operating Temperature Range Limitations:	
3.2 Cor	nponent Descriptions	
3.2.1	CO ₂ Cylinder Valve Assemblies	
3.2.2	Cylinder Mounting Bracket	
3.2.3	Firetrace Flexible Detector/Actuation Tubing	
3.2.4	Discharge Nozzle	
3.2.5	Pressure Switch	
3.2.6	Recharge Adapters, CO ₂ Cylinder	
3.2.7	Cylinder N ₂ Recharge Adapter	
3.2.8	CO ₂ Warning Nameplate	
4.0 SYST	EM DESIGN AND LIMITATIONS FOR TOTAL FLOODING	
	neral	
	sign Procedure	
	zard Enclosure Volume Limitations	
	neral Specifications	
4.4.1	Discharge Time:	
4.4.2	0	
4.4.3		
4.5 Min	imum Design Concentrations	
	enings and Ventilation Shutdown	
•	² Design Concentration Flooding Factors	
	ximum Protected Volume	
4.8.1	Example Calculations	19
4.9 Noz	zzle and Discharge Tubing Requirements	
4.9.1	Discharge Nozzle Limitations	
4.9.2	Discharge Piping & Fitting Specifications	
4.9.3	Maximum Piping and Fitting Limitations	20
4.10 Fire	etrace Detector Tubing	20
5.0 INST	ALLATION INSTRUCTIONS	22
	2 Cylinder/Valve and Bracket Assemblies	
	charge Piping and Nozzles	
	etrace Detection Tubing	
5.4 Pre	ssurization of Firetrace Detection Tubing	23
	ICE, MAINTENANCE, & FILLING INSTRUCTIONS	

6.1	General	25
6.2	Periodic Service and Maintenance	
6.3	Periodic Service and Maintenance Procedures	
6.3	1 Weekly/Monthly: Performed by Owner or End User	
6.3		
6.3		
6.4	Post Fire Maintenance	
6.4		
6.5	CO ₂ Cylinder Retest	
6.6	Filling Procedures	
APPENI	A	
System	n Parts List	
•	rge Line Parts List	
	ion Line Parts List	
Comp	onent Drawings	
-	oval Guide Listing	
	DIX B	

1.0 FORWARD

1.1 General

This manual is written for the fire protection professional that designs, installs, and maintains Firetrace Pre-engineered Automatic High Pressure Carbon Dioxide (CO₂) Extinguisher Units.

Firetrace CO_2 automatic high-pressure extinguisher units are to be designed, installed, inspected, tested, maintained, and recharged by qualified trained personnel in accordance with the following:

- All instructions, limitations, etc. contained in this manual P/N 800024
- All information contained on the agent cylinder nameplate(s)
- NFPA 12, Standard on Carbon Dioxide Extinguishing Systems 2015 Edition.
- FM Approval Listing* (please refer to Appendix A for the FM Approval system specifications and limitations)
- Local Authority having jurisdiction

* FM approval for flammable liquid hazards only

1.2 Safety Precautions

Safety precautions are essential when any electrical or mechanical equipment is involved. These precautions should be followed when handling, servicing, and recharging Firetrace CO₂ automatic high-pressure extinguisher unit cylinders and equipment. If safety precautions are overlooked or ignored, personal injury or property damage may occur.

The following symbols are used throughout this manual. Always heed these precautions. They are essential to the safe use of the equipment described in this manual.

A DANGER:

This danger symbol identifies immediate hazards and provides specific instructions or procedures, which if not correctly followed WILL result in severe personal injury or death.

A WARNING:

This warning symbol identifies specific instructions or procedures, which, if not correctly followed, COULD result in severe personal injury of death.

This caution symbol identifies specific instructions or procedures, which, if not correctly followed, COULD result in minor personal injury or equipment or property damage. The following safety precautions should always be followed:

Pressurized (charged) cylinders are extremely hazardous and if not handled properly are capable of causing bodily injury, death or property damage.

- 1. Read and understand this manual and the other documents referenced herein.
- 2. The valve discharge outlet safety cap and filling port cap **MUST** be installed on the cylinder valve at all times and only removed when connected into the discharge tubing, or when performing testing, or salvaging operations in accordance with the procedures contained in this manual.
- Wear safety glasses when working with pressurized cylinders and charging equipment. It is recommended to wear leather gloves to avoid any cryogenic burns if CO₂ is accidentally discharged on or near the skin.
- 4. Make sure that the ball valve (attached to the cylinder valve) is closed (lever is in "OFF" position), the detection tubing has been removed from the cylinder valve; and the safety caps installed, before removing the cylinder from the installation, and before performing any charging, leak tests or salvage operations.
- 5. Follow all of the safety procedures included on the cylinder nameplate and in this manual.
- 6. Never assume that a cylinder is empty. Treat all cylinders as if they are fully charged.

Any questions concerning the information contained in this manual should be addressed to:

Firetrace USA LLC.

8435 N 90th St, Suite 2 Scottsdale, AZ 85258 USA

Telephone: 480-607-1218 Fax: 480-315-1316

Email: firetrace@firetrace.com

The following web site should be visited for frequent technical announcements

www.firetrace.com

2.0 INTRODUCTION

The following Firetrace High Pressure CO₂ Automatic Fire Extinguisher Units are approved with FM Approvals:

950504 951004952004*(*With restrictions. See 4.3 Hazard Enclosure Volume Limitations)

These units are designed for total flooding using CO₂, in accordance with NFPA 12, *Standard on Carbon Dioxide Extinguishing Systems.* 2015 Edition

The Firetrace Pre-Engineered Automatic High Pressure Units have been tested to limits established by FM in compliance with the requirements detailed in this manual.

Each installed pre-engineered unit is equipped with its' own detection and its own discharge tubing and nozzles. The pre-engineered concept minimizes the amount of engineering involved in the units design. When the discharge tubing and nozzles are installed within the limitations stated in this manual, no hydraulic calculations are required to determine pressure drop, agent flow or discharge time.

The hazard being protected can be any size, shape or volume, provided that the hazard being protected is within the limitations described in this Manual (please refer to Appendix A for the FM Approval system specification and limitations). Each extinguisher unit, when installed, is a self-contained unit, meaning that it is equipped with its own automatic (non-electric) detection system, which when actuated, automatically releases the suppression agent into the hazard area.

Local authorities having jurisdiction should be consulted as to the acceptability for particular hazards and requirements covering installation.

2.1 Carbon Dioxide Extinguishing Agent

The extinguishing agent used in Firetrace pre-engineered automatic high-pressure extinguisher units is Carbon Dioxide, more commonly known as CO₂. CO₂ is a colorless, odorless, electrically nonconductive inert gas that is an extremely effective fire suppression agent.

2.1.1 Cleanliness

 CO_2 is clean and leaves no residue, thereby minimizing any after fire clean up, along with keeping expensive downtime to a minimum. Most materials such as steel, aluminum, stainless steel, brass, as well as plastics, rubber and electronic components are not affected by exposure to CO_2 . This agent is also environmentally friendly, having an ozone depletion potential (ODP) of 0.00.

2.1.2 Physical Properties of Carbon Dioxide

Chemical Name: Carbon Dioxide

Molecular Weight Boiling Point (°F) @ 14.7psia Freezing Point (°F) Critical Temperature (°F) Critical Pressure (psia) Critical Density (lbm/ft3) Specific Heat, Liquid (BTU/Lb-°F) @ 2°F Specific Heat, Vapor (BTU/Lb-°F) @ Constant Pressure (1 ATM) @ 77°F Heat of Vaporization (BTU/lb) @ Boiling Point Thermal Conductivity (BTU/hr ft oF) of Liquid @ 77°F Viscosity, Liquid (lb/ft hr) @ 77°F	0.489	44.01 -109.3 -69.9 87.9 1071 29.2
Vapor Pressure (psig) @ 70°F Ozone Depletion Potential		838 0.00

2.1.3 Fill Density

Each Firetrace CO₂ storage cylinder has been designed for a maximum fill density as shown in Table 3.1. It is important that these values not be exceeded.

Fill density and temperature significantly affect the pressure in the storage cylinder. At elevated temperatures the rate of increase in pressure is very sensitive to fill density (see Figure 2.1). If the maximum fill density is exceeded; the pressure will increase rapidly with temperature increase so as to present a hazard to personnel and property. Adherence to the limits on fill density and pressurization levels will prevent excessively high pressures from occurring if the storage cylinder is exposed to elevated temperature. This will also minimize the possibility of an inadvertent discharge of agent through the cylinder pressure relief device, where provided. It is recommended to not mount the cylinder in direct sunlight as this would create elevated cylinder temperatures.







3.0 SYSTEM DESCRIPTION

3.1 General

The Firetrace CO₂ Automatic High Pressure units are FM Approved in 3 sizes (please refer to Appendix A for the FM Approval system specifications and limitations), namely:

950504	Charged with 5.0 Lbs. of CO ₂
951004	Charged with 10.0 Lbs. of CO ₂
952004	Charged with 20.0 Lbs. of CO ₂

These units are designed for use in Total Flooding applications where the hazard is not occupied by a human being. A lock-out valve shall be provided on all systems except where dimensional constraints prevent personnel from entering the protected space.

The Firetrace CO2 units can be used, but are not limited, to protect the following:

- Electrical and electronic cabinets
- Telecommunication areas
- Data Processing areas and cabinets
- Other high value assets
- Laboratory fume /exhaust cabinets
- Pump enclosures
- UPS units
- Flammable Chemicals storage cabinets
- Generator Enclosures
- Transformer Cabinets
- Computer/Data Storage Cabinets
- CNC & VMC Machining centers
- Many other applications

CO₂ is a gaseous fire-extinguishing agent that is effective for use on (please refer to Appendix A for the FM Approval system specifications and limitations):

- Class A
 - \Rightarrow Surface type fires
 - \Rightarrow Deep seated fires
- Class B Flammable liquid fires
- Class C Electrical equipment fires

CO₂ should not be used where the following materials may be present.

- Pyrotechnic chemicals containing their own oxygen supply
- Reactive metals such as lithium, sodium, potassium, magnesium, titanium, zirconium, uranium and plutonium
- Metal hydrides
- Chemicals capable of undergoing auto thermal decomposition, such as certain organic peroxides and hydrazine

For hazards beyond the scope described above, it is recommended that the designer consult with Firetrace, NFPA 12, and the local authority having jurisdiction, as to the

suitability on the use of CO₂ for a particular hazard, for personnel exposure effects from the design concentration, and for installation requirements.

Firetrace CO₂ Automatic High Pressure Extinguisher Units consist of the following major components:

- CO₂ Cylinder/Valve assembly
- Cylinder Mounting Bracket
- Firetrace detector/actuation tubing and fittings (no substitute)
- Discharge nozzles
- Discharge Port Adapter
- Pressure switch
- Discharge tubing and fittings (furnished by others)

Once installed, the Firetrace Automatic High Pressure Unit becomes a self-contained, self-actuating unit that does not require an external source of power or electricity.

The unit utilizes a UL recognized component (per UL standard 521), a Linear Heat Detector (See Certificate of Compliance 20140705-S35465) known as Firetrace Automatic Detection Tubing, which when pressurized with Dry Nitrogen, will allow the fire suppression valve to remain in the closed position. This tubing acts a continuous linear thermal detector that ruptures upon direct flame impingement or at temperatures above $383^{\circ}F$ (195°C). Once the detector tubing is ruptured, the cylinder valve automatically opens, allowing the CO₂ agent to flow through the discharge tubing, distributing the extinguishing agent through the nozzle(s) onto the protected area. Upon actuation, the pressure switch can be used to indicate discharge, shutdown ventilation, close all openings, shut-off electrical power, etc. as may be required.

3.1.1 Operating Pressure

The CO₂ cylinder is stored as a liquefied gas under its own pressure; 838 psig @ 70°F.

3.1.2 Operating Temperature Range Limitations:

The ambient operating temperature range for all unit components is: 0° F to +130°F (-17.8°C to +54.4°C).

3.2 Component Descriptions

3.2.1 CO₂ Cylinder Valve Assemblies

 CO_2 is stored in DOT/TC aluminum cylinders as a liquefied compressed gas, under its own pressure; 838 psig @ 70°F (5,778 KPa @ 21°C). The cylinder/valve assemblies are FM Approved (please refer to Appendix A for the FM Approval system specifications and limitations) in 3 sizes, namely:

5 LB size filled with 5.0 LBS (2.27 Kg) of CO₂ 10 LB size; filled with 10.0 LBS (4.54 Kg) of CO₂ 20 LB size; filled with 20.0 LBS (9.07 Kg) of CO₂

Each cylinder is equipped with a brass valve and a quarter turn ball valve that interfaces with the Firetrace detector tubing. The ball valve must be kept closed at all times when the cylinder is not in service.

800024-004

In addition, the CO₂ Cylinder valves are equipped with a pressure relief (rupture disc) device in compliance with DOT/TC requirements.

Each valve is also equipped with (1) discharge outlet port and (1) filling port. Each port is provided with a safety cap that must be installed whenever a cylinder is not in service. These caps are safety devices designed to prevent uncontrolled discharge of the cylinder in the event that the valve is accidentally actuated.

The safety caps must be installed on the valve discharge port and filling port at all times, except when connected into the units discharge tubing or when filling. Failure to follow these instructions could result in personal injury, death or property damage.

Table 3.1 describes the 5, 10, and 20 LB cylinder assemblies. Each cylinder is equipped with a straight siphon tube and can only be mounted in a vertical (upright) position.

Nom Size	Assy Part		side ia.		erall ight		ernal lume	C(Age		Fill Densit y
	No.	in.	cm	in.	Cm	in ³	cm ³	lb.	kg	%
5	950504	5.25	12.70	20.0	50.67	205	3359	5.0	2.27	68
10	951004	6.89	17.50	22.4	55.32	408	6717	10.0	4.54	68
20	952004	8.00	20.32	29.0	72.14	816	13340	20.0	9.07	68

Table 3.1:	CO ₂ Cylinder / Valve Assemblies	
------------	---	--

Table 3.2 describes the DOT/TC Specifications used for the manufacture of the CO_2 cylinders.

Nominal	DOT	тс	Cylinder Service	Test Pr	essure
Size	Spec	Spec	Pressure	DOT	ТС
			psig	psig	psig
5	3AL1800	3ALM124	1800	3000	2700
10	3AL1800	3ALM124	1800	3000	2700
20	3AL1800	3ALM124	1800	3000	2700

The Firetrace CO_2 Units are designed for an operating temperature range of 0°F to +130°F. Table 3.3 shows the cylinder, pressure-temperature relationship based on a maximum fill density of 68%; and a charged pressure of 838 psig at 70°F

800024-004

Cylinder Pressure					
Tempe	erature	Press	sure		
°F	O°	psig	kPa		
32	0.00	505	3,481		
40	4.44	567	3,909		
50	10.00	652	4,495		
60	15.56	747	5,150		
<mark>70</mark>	<mark>21.11</mark>	<mark>852</mark>	<mark>5,874</mark>		
80	26.67	975	6,722		
90	32.22	1205	8,308		
100	37.78	1465	10,100		
110	43.33	1725	11,893		
120	48.89	1995	13,755		
130	54.44	2265	15,616		
140	60.00	2545	17,547		
150	65.56	2825	19,477		

 Table 3.3:
 Cylinder Pressure-Temperature Relationship

3.2.2 Cylinder Mounting Bracket

A wall mounted painted steel bracket is used to mount the 5, 10, and 20lb cylinder/valve assemblies in a vertical (upright) position. Each bracket is equipped with an interlocking steel strap that is secured with a metallic pin.

3.2.3 Firetrace Flexible Detector/Actuation Tubing

The Firetrace detection/activation tubing is a UL recognized component per UL standard 521 (See Certificate of Compliance 20140705-S35465). The Firetrace tubing is used as a combination linear heat detector and unit activation device to cause actuation of the CO_2 agent cylinder. The tubing is installed throughout the hazard volume, with one end connected to the CO_2 cylinder valve. The tubing is pressurized with nitrogen to 195 psig while maintaining the ball valve in the "OFF" position. An optional pressure gauge or pressure switch can be connected to the other end of the detector tube to monitor tubing pressure and/or signal unit actuation etc. The detector tubing is heat sensitive and in a fire situation is designed to rupture upon direct flame impingement or at any point along the tube when the temperature reaches $383^{\circ}F$ ($195^{\circ}C$). The rupture of the tube releases the nitrogen pressure causing the CO_2 cylinder valve to actuate, resulting in complete discharge of the CO_2 agent through the nozzles.

3.2.4 Discharge Nozzle

Discharge nozzles are used to distribute CO₂ agent uniformly throughout the hazard area. One size nozzle is available for use with all IHP models, and must be used within the limitations described in this Manual

3.2.5 Pressure Switch

A pressure switch is available as an optional item. This switch can be connected at the end of the line of the Firetrace detector tubing to monitor unit pressure, unit actuation and or to energize or de-energize electrically operated equipment. Firetrace recommends that all units use a pressure switch coupled with some device to alert personnel in the event of discharge.

3.2.6 Recharge Adapters, CO₂ Cylinder

The recharge adapter is connected to the filling port located on the cylinder valve during the cylinder recharging procedure. The adapter is used for refilling the cylinder with CO₂.

3.2.7 Cylinder N₂ Recharge Adapter

The recharge adapter is connected to the Firetrace tubing, and the other end of the tubing is attached to the ball valve, located on the cylinder valve, during the charging procedure. The adapter is used to apply nitrogen pressure to the detection tubing, and to keep the valve piston seated.

3.2.8 CO₂ Warning Nameplate

The Warning Plate is required to warn personnel not to enter the hazard area during or after discharge. Warning signs shall be provided in a conspicuous location, at the entrance to the protected areas, or in the case of cabinet protection on the front face of the cabinet. Signs must be in accordance with NFPA 12, Section 4.3.

4.0 SYSTEM DESIGN AND LIMITATIONS FOR TOTAL FLOODING

4.1 General

The Firetrace series of CO₂ Pre-Engineered Automatic High Pressure Extinguisher units were tested and limits established by Firetrace and Factory Mutual. These units were subjected to numerous performance tests, in order to verify their suitability and to establish design limitations for:

- Hazard volume
- Nozzle placement
- Discharge time and flow rates
- Design concentrations and design factors
- Detector tubing placement

The pre-engineered automatic unit concept minimizes the amount of engineering required when evaluating a design for a specific application. So long as the discharge piping, tubing, and nozzles are installed within the limits prescribed in this manual, no calculations are required for pressure drop, flow rates or discharge time. When the additional limitations of hazard volume, design concentration, agent quantity, detector arrangement, etc., are also met, the unit installation can be understood to comply with the design requirements, NFPA 12, and FM Approval (please refer to Appendix A for the FM Approval system specifications and limitations).

4.2 Design Procedure

The following procedures should be used to design a Firetrace CO_2 pre-engineered IHP automatic extinguisher unit. In addition, the applicable requirements specified in NFPA 12 should be followed.

- a. Conduct a survey and analysis of the hazard to be protected
- b. Determine the height, length, and width of the enclosure. Calculate the volume. All of these parameters must be within the dimensional limits specified in this manual. (See Section 4.3, Table 4.1).
- **c.** Determine the anticipated minimum and maximum ambient temperatures expected within the enclosure to be protected.
- **d.** Determine the minimum design concentration required for the hazard. (See Section 4.5 and Table 4.3).
- e. Determine the integrity of the enclosure. Are there any openings that must be closed at the time of agent discharge? (See Section 4.6).
- f. Calculate the quantity of CO₂ agent required, with the proper design concentration, to protect the enclosed space. (Refer to Section 4.7 and Example 4.8.1).
- **g.** Determine the cylinder size required, based on the hazard volume limitations, enclosure size, and quantity of CO₂ agent required.
- **h.** Determine the location of the CO₂ cylinder.
- i. Determine the location and quantity of nozzles required, based on the size and configuration of the enclosure. (See Section 4.9 and Table 4.6).
- **j.** Determine the routing and quantity of discharge pipe (tubing) required. The discharge pipe (tubing) and fitting limitations must not be exceeded. (See Section 4.9 and Table 4.6).

- **k.** Determine the arrangement and placement of the Firetrace detection tubing. (See Section 4.10).
- I. Determine any auxiliary equipment requirements, such as pressure switch(s) to sound alarms, shut-down ventilation, shut-off electrical power, etc..
- **m**. Prepare system drawings, bill of materials list, etc; following Section 4.4 of NFPA 12 2015 Edition.

4.3 Hazard Enclosure Volume Limitations

The maximum volume for each size unit is shown in Table 4.1. The protected enclosure can be any size or shape provided that the volume does not exceed the limitations shown in Table 4.1 with the exception of the IHP-2000 as noted below.

Model	CO₂ (Lbs)	Volume (Ft ³)			
950504	5.0	70			
951004	10.0	140			
952004	20.0	300*			
	 * At least one dimension (I, w, h) must not exceed 2 feet Volumes are based on 34% Design Concentration 				

Table 4.1: Enclosure Size Limitations

4.4 General Specifications

4.4.1 Discharge Time:

Surface fires: The design concentration must be achieved within 1 minute from start of discharge.

4.4.2 Storage and Operating Temperature Range:

The Firetrace CO_2 units and equipment are designed to be stored and operated at an ambient temperature range of 0°F to +130°F. (-17.8°C to +54.4°C).

4.4.3 System Operating Pressure:

The normal operating pressure for the unit is 838 psig at 70°F.

4.5 Minimum Design Concentrations

The minimum design concentrations to be used with Firetrace CO₂ units shall not be less than 34%. For class B hazards, proper consideration must be given to the material involved in the hazard, the design concentration should then be given a safety factor (SF) of 20%, as specified in NFPA 12, Year 2015 edition.

Table 4.2:	Minimum	Safety Factor
------------	---------	---------------

Hazard Type	Minimum Safety Factor
Class B Flammable Liquids	20%

Table 4.3 lists CO_2 minimum design concentrations that must be used with Firetrace CO_2 units for Class A hazards and the various Class B fuels shown.

Consult Firetrace website, or contact Firetrace if the hazard you desire to protect is not listed.

Material	Theoretical Minimum CO₂ Concentration %	Minimum Design CO ₂ Concentration %
Class A (surface fires) ^(a) Including plastic materials typically found in electrical/electronic equip.	34	34
Class B fuels ^(b)		
Acetylene	55	66
Acetone	27	34
Aviation Gas Grades 115/145	30	36
Benzol, Benzene	31	37
Butadiene	34	41
Butane	28	34
Butane-I	31	37
Carbon Disulfide	60	72
Carbon Monoxide	53	64
Coal or Natural Gas	31	37
Cyclopropane	31	37
Diethyl Ether	33	40
Dimethyl Ether	33	40
Dowtherm	38	46
Ethane	33	40
Ethyl Alcohol	36	43
Ethyl Ether	38	46
Ethylene	41	49
Ethylene Dichloride	21	34
Ethylene Oxide	44	53
Gasoline	28	34
Hexane	29	35
Higher Paraffin Hydrocarbons C _n H _{2m} + 2m - 5	28	34

 Table 4.3:
 Minimum Carbon Dioxide Concentrations for Extinguishment

Hydrogen	62	75
Hydrogen Sulfide	30	36
Isobutane	30	36
Isobutylene	26	34
Isobutyl Formate	26	34
JP-4	30	36
Kerosene	28	34
Methane	25	34
Methyl Acetate	29	35
Methyl Alcohol	33	40
Methyl Butene - I	30	36
Methyl Ethyl Ketone	33	40
Methyl Formate	32	39
Pentane	29	35
Propane	30	36
Propylene	30	36
Quench, Lube Oils	28	34
Note: The theoretical minimum extinguishing	concentrations in air for the materia	ls in the table were obtained

Note: The theoretical minimum extinguishing concentrations in air for the materials in the table were obtained from a compilation of Bureau of Mines, *Limits of Flammability of Gases and Vapors* (Bulletins 503 and 627)

For all materials not given in Table 4.3, the minimum theoretical carbon dioxide concentration shall be obtained from some recognized source or determined by test.

4.6 **Openings and Ventilation Shutdown**

Provisions must be made to provide means to close all openings in the hazard enclosure and shut-off ventilation at the time of discharge.

4.7 CO₂ Design Concentration Flooding Factors

The total flooding quantity of CO₂ agent needed to protect an enclosure containing a material requiring a 34% design concentration can be found in Table 4.4.

To find the total quantity of CO_2 required, multiply the hazard volume by the Volume Factor found in Table 4.4

If the design concentration is greater than 34%, the basic quantity calculated from Table 4.4 shall be multiplied by the corresponding conversion factor found in Figure 4.1.

This table should only be used for materials requiring a 34% CO₂ Design Concentration. And for environments where the temperature range is between 0-130 ° F

(A) Volume of Space	(B) Volume Factor		(C) Calculated Quantity (LB)
(Ft ³)	Ft ³ /lb CO ₂	lb CO ₂ /Ft ³	(Not Less Than)
Up to 140	14	0.072	
141-500	15	0.067	10
501-1600	16	0.063	35
1601-4500	18	0.056	100
4501-50,000	20	0.050	250
Over 50,000	22	0.046	2500

 Table 4.4:
 Flooding Factors for 34% Concentration.



Figure 4.1: Conversion Factor for Design Concentrations Greater than 34%.

4.8 Maximum Protected Volume

The maximum volume that can be protected by the Firetrace CO_2 units is dependent on the minimum design concentration. The maximum volumes calculated from Table 4.4 for concentrations of 34% for Firetrace CO2 systems are listed below.

Model	Volume (ft3)
950504	Up to 70
951004	71 to 140
952004	141-300

Table 4.5:	Maximum	Protected	Volume for	IHP Systems
	Maximum	1 10100100	volume for	IIII Oystoms

4.8.1 Example Calculations

The requirements given in Sections 4.1 through 4.8 describe the procedures to be used to design and size a Firetrace IHP CO_2 unit.

The following example provides guidelines, following procedures 4.2.a, through 4.2.e., in order to determine the quantity of CO_2 agent required and cylinder size for a total flooding application.

Example:

Given:

- Hazard Small cabinet storing Ethyl Alcohol.
- Class B hazard
- Enclosure size: 4' wide x 4' long x 6' high. One (1) access door equipped with self closing apparatus
- Minimum anticipated ambient temperature: 50°F
- Maximum anticipated ambient temperature: 90°F

Procedure:

- **a.** Determine min. design concentration required (Refer to Table 4.3 Use 43% min. design concentration for Ethyl Alcohol.
- **b.** Calculate hazard volume (V). V = 4' x 4' x 6' =96 Ft^3
- c. Calculate quantity (Q) of CO₂ required first using volume factor for 34% concentration (Refer to Table 4.4) volume of 96 Ft³ shows that a Volume Factor 0.072 Lb CO₂/Ft³

Q = 96 Ft³ x 0.072 Lb CO₂/Ft³ = 6.912 Lbs. of CO₂ is required. Because this is based on a 34% concentration, it must be multiplied by the conversion factor, which can be found in Figure 4.1. For a design concentration of 43%, the conversion factor is 1.25. Qtotal = 6.912 x 1.25= 8.64 Lbs (This then requires the use of a 951004 with 10 Lbs of CO2)

4.9 Nozzle and Discharge Tubing Requirements

4.9.1 Discharge Nozzle Limitations

One size nozzle P/N 510010 is to be used with all Firetrace IHP CO₂ extinguisher units in total flooding applications.

Placement of nozzles shall be such that discharge of CO₂ will not splash flammable liquids or create dust clouds that could extend the fire.

More than one nozzle can be used to protect a particular hazard, as long as the "Equivalent Length of Pipe" for Firetrace IHP CO₂ systems is not exceeded. Refer to section 4.9.3 for information regarding the "Equivalent Length of Pipe".

4.9.2 Discharge Piping & Fitting Specifications

All Firetrace IHP Units shall use steel piping for the distribution system. The following piping and fittings shall be used.

Piping Specifications:

Material:	Black or Galvanized steel pipe
Туре:	ASTM A 53 seamless or electric welded, Grade A or B
Size:	1/2 Pipe
Note: For oth	ner options consult NFPA 12 2015 Edition Section 4.7

Pipe Fitting Specifications:

Material:	Malleable or ductile iron fittings
Туре:	Class 300

4.9.3 Maximum Piping and Fitting Limitations

The maximum "Equivalent Length of Piping" shall not exceed 24 ft. The "Equivalent Length of Piping" includes individual lengths of pipe and all pipe fittings. Table 4.6 includes the equivalent lengths of $\frac{1}{2}$ inch threaded pipe fittings that need to be considered when determining the total "Equivalent Length of Piping".

Pipe Size	Elbow Std. 45°	Elbow Std. 90°	Elbow 90° Long Radius & Tee Thru Flow	Tee Side	Union Coupling
1/2	0.8	1.7	1.0	3.4	0.4

Table 4.6: Equivalent length in feet of threaded pipe fittings.

4.10 Firetrace Detector Tubing

The Firetrace detection/activation tubing is a UL recognized component per UL standard 521 (See Certificate of Compliance 20140705-S35465). For the Indirect CO_2 units, the Firetrace tube is used as a combination heat detector and unit activation device to cause actuation of the CO_2 agent cylinder.

The detector tubing is heat sensitive and in a fire situation is designed to rupture upon direct flame impingement or at any point along the tube when the temperature reaches 383°F (195°C).

Location and spacing of the tubing is critical to the response time in the event of a fire. The tubing should be placed above the hazard areas being protected. The drawing in Appendix A provides general guidelines for placement of the detector tubing along with the maximum spacing and height limitations. Depending on the configuration of specific hazards, the guidelines may, or may not, be applicable. The maximum length of tubing that can be used for any IHP unit is 120 feet. The maximum height that is allowed between layers is 3.28 feet. The maximum distance between passes is 21.12 inches.

NOTE: It is recommended that the tubing **not** be placed horizontally adjacent to potential fire sources as this may significantly delay response time.

5.0 INSTALLATION INSTRUCTIONS

This section provides installation instructions covering components and limitations described in Sections 3 and 4 of this manual.

All components should be installed to facilitate proper inspection, testing, recharging, and any other required service or maintenance as may be necessary. Equipment must not be subjected to severe weather conditions or mechanical, chemical, or other damage, which could render the equipment inoperative. The equipment must be installed in accordance with instructions in this manual and NFPA 12.

🛕 WARNING

 CO_2 cylinder/valve assemblies must be handled, installed, and serviced in accordance with the instruction contained in this manual and on the cylinder nameplate. Failure to follow these instructions could result in severe injury, property damage or death.

5.1 CO₂ Cylinder/Valve and Bracket Assemblies

The CO₂ cylinders should be located as close as possible to the protected enclosure. In some cases, the cylinder can be mounted inside the protected enclosure. The assemblies shall be located in a readily accessible location to allow for ease of inspection service and maintenance. The cylinders shall be located in an environment protected from the weather and where the temperature range is between $0^{\circ}F$ and + $130^{\circ}F$.

Cylinder and bracket must be mounted in the vertical plane with the cylinder valve facing up.

Mount the cylinder where it will not be subject to accidental damage or movement. Suitable protection must be installed where necessary to prevent damage or movement.

A CAUTION

Make sure that the ball valve, located on the cylinder valve, is maintained in the "OFF" position, and the discharge port safety caps are in place. Failure to follow these instructions will result in actuation and discharge of the cylinder contents.

1. Securely mount the cylinder bracket to structural support using 2 or more mounting holes.

2. Secure cylinder in place using the bracket strap.

5.2 Discharge Piping and Nozzles

1. Locate the nozzle(s) following the guidelines and limitations described in Section 4.9.

- 2. Determine the routing of the discharge piping following the guidelines and limitations described in Section 4.9
- 3. Remove the safety cap from the valve discharge port as required. Attach female connection fittings (Firetrace P/N 200201) onto discharge port.
- 4. Install the necessary piping and fittings between the cylinder and nozzle(s). Secure piping with appropriate size piping clamps as required.

5.3 Firetrace Detection Tubing

- 1. Do not kink, bend, or crush Firetrace tubing in order to prevent leakage, which could result in accidental unit discharge.
- 2. Do not install tubing in a hazardous environment where the maximum ambient temperature exceeds 176°F (80°C)
- 3. Do not place the tubing on a surface where the temperature of the surface exceeds 140°F (60°C)
- 4. Maximum length of detector tubing shall not exceed 120 Feet.
- 1. Follow guidelines as outlined in section 4.10 and the drawing in Appendix A for the tubing placement.
- 2. Secure detection tubing using Mounting Tabs at 1.5 ft. intervals.
- 3. Use appropriate rubber/plastic grommets when detection tubing is routed through sharp holes in order to prevent damage to the tubing.
- 4. Connect the end of line adapter and spring top unit to the detection tubing as shown in Appendix A.
- 5. When installing tubing to the cylinder valve make sure that the detection tubing is pushed through the top of the ball valve inlet all the way through to the shoulder and then tighten the spring top unit to a torque of 4-6 Nm.
- 6. Ensure the detection tubing is pushed through the end of line adapter all the way through to the shoulder. Then tighten the spring top unit to the end of line adapter to a torque of 4-6 Nm.
- 7. The detector tubing is now ready to be pressurized with nitrogen. (See section 5.4 for pressurization procedure)

5.4 Pressurization of Firetrace Detection Tubing

- 1. Attach the filling adapter (P/N 600023) to the detector-tubing end of line adapter.
- 2. Using a regulated dry nitrogen supply, pressurize the detection tubing with dry nitrogen through the filling adapter to 195 psig. It is recommended to have a portable dry nitrogen cylinder for on site use.

- 3. Remove the filling adapter and attach calibrated test pressure gauge & 0-ring to verify that the tubing is pressurized to at least 195 psig at 70°F.
- 4. With gauge still attached to the end of line adapter, test for leakage.
 - Apply soapy water solution to the cylinder valve connection, end of line adapter connection, and the pressure gauge connection. Observe for bubble leaks.
 - Wait 30 minutes, then observe pressure gauge. Any decrease in pressure is an indication of a leak.
 - In the event of a leak go back to Section 5.3 and repeat steps 4, 5, & 6.
 - If no leaks are observed proceed to step 5 of Section 5.4
- 5. If an optional pressure switch is to be installed in the EOL adapter, remove pressure gauge and install the washer and pressure switch using wiring instructions located on the device. Check pressure switch connection for bubble leaks using soapy water solution.
- 6. After confirming that there is no leakage within the detector tubing, <u>SLOWLY</u> rotate the ball valve lever counter clockwise to the "ON" position.

If the ball valve lever is opened abruptly this may result in activation of the cylinder valve and unit discharge.

- 7. Tamper proof the unit by choosing one of the options below
 - a. Option #1 Remove the ball valve lever completely. Follow directions for removal of lever listed in Appendix A.
 - b. Option #2 Attach tamper seal around the ball valve lever to secure it in the "ON" position, which is the set/ready position also shown in Appendix A.
- 8. Ensure appropriate electrical connections to the optional EOL pressure switch, which can be used to annunciate unit discharge, shut down ventilation, etc., as may be required by the end user or the AHJ. (All electrical connections are to be in accordance to NFPA 70 National Electric Code)
- 9. Attach the warning nameplate(s) (Firetrace P/N 800031) to the appropriate locations.
- 10. Unit is now fully armed and ready for use.

6.0 SERVICE, MAINTENANCE, & FILLING INSTRUCTIONS

- 1. CO₂ cylinder/valve assemblies must be handled, installed, inspected and serviced only by qualified and trained personnel in accordance with the instructions contained in this manual, the cylinder nameplate, NFPA 12, and any other regulations and codes that may apply.
- 2. Before performing maintenance or refilling procedures refer to the material safety data sheets in the appendix at the back of this manual.

6.1 General

A regular program of systematic maintenance must be established for continuous, proper operation of all CO_2 units, and to avoid violating the warranty. A periodic maintenance schedule must be followed and an inspection log maintained for ready reference. As a minimum, the log must record: (1) inspection interval, (2) inspection procedure performed, (3) maintenance performed, if any, as a result of inspection, and (4) name of inspector performing task.

6.2 Periodic Service and Maintenance

Perform service and maintenance of the CO_2 unit in accordance with the schedule shown in Table 6.2

Schedule	Requirement	Reference Paragraph
Weekly	Visually inspect unit components	6.3.1
Monthly	Visually inspect unit components.	6.3.1
Semi-Anually	Check CO ₂ cylinder weight. Check nozzles for obstruction.	6.3.2
Every 5 Years	Perform external visual inspection of CO ₂ Cylinders.	6.3.3

Table 6.2:	Periodic service	and maintenance schedule.
1 abie 0.2.	F EIIUUIC SEIVICE	and maintenance schedule.

6.3 Periodic Service and Maintenance Procedures

6.3.1 Weekly/Monthly: Performed by Owner or End User

- 1. Make a general visual inspection of the CO₂ cylinder and equipment for damaged or missing parts.
- 2. Ensure access to hazard areas, discharge nozzles, and cylinders are unobstructed and that there are not obstructions to the operation of the equipment or distribution of CO₂ agent.
- 3. Inspect detection tubing in hazard area for abrasion, distortion, cuts, or dirt accumulation, and that there are no obstructions preventing tubing from sensing a fire should one occur.
- 4. Verify that there have been no changes in the size of the enclosure and that no new ventilation has been added.

6.3.2 Semi-Annual Inspection

- 1. Check CO₂ cylinder for weight.
- 2. Remove cylinder from the installation as follows:
 - Close ball valve, by turning ball valve lever clockwise to the "OFF" position.
 - Disconnect detector tubing at the ball valve. Note: There will be a loss of nitrogen pressure out of the tubing.
 - Disconnect piping and fittings from the cylinder valve discharge port.
 - Immediately install safety cap onto the valve discharge port.
 - Remove cylinder from bracket
- 3. Weigh cylinder. Compare measured weight with weight found on the cylinder nameplate. If the container shows a loss in agent quantity of more than 10 percent, the cylinder shall be refilled or replaced.
- 4. Remove nozzle(s) and inspect for obstructions. Reinstall nozzles.
- 5. Reinstall cylinder and re-pressurize detector tubing with nitrogen following the applicable procedures outlined in Section 5.0.

6.3.3 Five Year Inspection

CO₂ cylinders continuously in service without discharging shall be given a complete external visual inspection in place, every 5 years or more frequently if required.

6.4 Post Fire Maintenance

In the event of a unit discharge the following procedures shall be performed.

6.4.1 CO₂ Cylinder Valve

Remove the cylinder assembly from the installation following procedures detailed in Section 6.3.2, Step 2. Inspect and service the CO₂ cylinder valve as follows:

Prior to removal of the valve from the cylinder, verify that all pressure has been released. To relieve any remaining pressure loosen but do not remove the valve safety caps. Then open the ball valve to the "ON" position and allow any residual pressure to leak out past the plugs.

- 1 Only after verifying that the cylinder has been depressurized, remove valve from cylinder.
- 2 Perform a visual inspection of the valve to verify that no damage occurred due to the fire. If integrity of the valve looks compromised, contact Firetrace. The valve should not be serviced by anyone other than a Firetrace Technician.
- 3 Change the cylinder/valve o-ring. Discharge of CO₂ causes the o-ring to undergo vacuum decompression; failure to change the o-ring will result in leaks around the cylinder/valve connection.
- 3. Re-seat the piston in the valve by following the procedure in Section 6.6, Step 2.

6.5 CO₂ Cylinder Retest

Firetrace CO₂ cylinders are built to DOT-3AL specifications and therefore fall under DOT regulations for retest prior to refill.

DOT-3AL cylinders used exclusively in CO₂ service are required to be retested and restamped prior to recharge and shipment if the last retest date has expired.

Firetrace CO₂ (DOT-3AL) containers requiring retest must be hydrostatically tested in accordance with DOT CFR Title 49, Section 173.34(e). This periodic retest must be performed by an authorized retester having a current identification number issued by the Associated Administrator for Hazardous Material Safety of DOT, and must include an internal and external examination in accordance with CGA pamphlet C-6, C-6.1, C-6.2, or C-6.3, as applicable. The test procedures are described in CGA pamphlet C-1. Because volumetric expansion of the container must be measured, only the water jacket volumetric expansion method or the direct expansion methods are acceptable.

As an alternate option, CO_2 agent containers may be given a complete external visual inspection, as detailed in Section 173.34(e)(13), in lieu of hydrostatic test. The visual inspection shall only be made by competent persons. A person who performs the visual examination specified in 173.34(e)(13) is not required to have a re-tester's identification number.

Retest can be performed by either of the following methods:

Retest Method	First Retest Due (Yrs)	Subsequent Retest Due (Yrs)	Special Marking
Full by droototic toot			
Full hydrostatic test including determination of cylinder expansion.	5	5	Retest Date Month/Year
External visual inspection per paragraph			Retest Date
173.34(e)(13) and CGA pamphlet C-6, Section 3.	5	5	followed by "E"

6.6 Filling Procedures

- 1. Weigh and record cylinder empty weight with valve and the 2 safety caps installed.
- 2. Remove the safety cap from the discharge port and visually check that the piston is seated inside of the valve. Replace safety cap. (If piston is not seated, apply 195 psi of Nitrogen pressure through the ball valve. You will be able to hear the piston change positions. Return ball valve to "OFF" position and remove hose connection).
- 3. Remove safety cap from filling port and attach Firetrace CO₂ filling adapter (P/N 60024) to filling port
- 4. Attach CO_2 supply line to filling adapter. (CO_2 is to be pumped)
- 5. Place the cylinder, with supply line hooked up, on scale and zero the scale. Open the supply of CO_2 from bulk tank to fill the cylinder to the required weight.
- 6. Close supply of CO₂ while maintaining all connections.
- 7. Disconnect CO₂ recharge adapter and immediately attach discharge port cap to valve.

A CAUTION

Any hissing or discharge coming from vent valve indicates that the piston is not seating properly or has opened. If this occurs, repeat Step 10 and verify that the cylinder valve piston remains closed.

- 8. Verify weight by checking it against what is printed on the label.
- 9. Leak test the cylinder.
- 10. Cylinder is now ready to be transported to the installation site.

Note: All reasonable efforts must be made to prevent emitting any CO₂ to the environment during filling or servicing of Firetrace units.

APPENDIX A

SYSTEM PARTS LIST DISHARGE LINE PARTS LIST DETECTION LINE PARTS LIST COMPONENT DRAWINGS INSTALLATION DRAWINGS

System Parts List

5, 10, and 20 LB. PRE-ENGINEERED AUTOMATIC INDIRECT CO2 EXTINGUISHER UNIT

MODELS:	950504	5 LB. CO2 IHP
	951004	10 LB. CO2 IHP
	952004	20 LB. CO2 IHP

ITEM	PART NO.	DESCRIPTION	SYSTEM
1	310201	IHP Valve	All Systems
2	110050	5 Lb. Cylinder	5 LB
2	110100	10 Lb. Cylinder	10 LB
2	110200	20 Lb. Cylinder	20 LB
3	600008	Siphon Tube ⁵ / ₈ "x13 ¹ / ₄ "	5 LB
3	600005	Siphon Tube ⁵ / ₈ "x15 ¹ / ₄ "	10 LB
3	600006	Siphon Tube ⁵ / ₈ "x21 ¹ / ₄ "	20 LB
4	111201	5 Lb. Heavy Duty Bracket	5 LB
4	111010	10 Lb. Heavy Duty Bracket	10 LB
4	111020	20 Lb. Heavy Duty Bracket	20 LB
5	310310	Discharge Port Safety Cap	All Systems
6	310305	Collar O-Ring	All Systems
7	200160	Spring Top Support Unit	All Systems
8	600053	Pull Pin	All Systems
9	600007	Nameplate: CO2	All Systems
*	600125	Label: IHP CO2	All Systems
*	800100	Warranty/Registration Card	All Systems
*	200201	Discharge Port Adapter	All Systems
*PART N	NOT PICTURED		



Discharge Line Parts List

ITEM NUMBER	PART NUMBER	DESCRIPTION
*	200201	IHP Discharge Port Adapter
3	510010	Small Total Flood Nozzle
4	500024	Total Flooding Nozzle
1	510015	IHP Wide Dispersion Nozzle
2	510016	IHP Narrow Dispersion Nozzle
*	201802	2' Hydraulic Discharge Hose With Elbows
*	201804	4' Hydraulic Discharge Hose With Elbows
*	201806	6' Hydraulic Discharge Hose With Elbows
*	201808	8' Hydraulic Discharge Hose With Elbows
* PART NO	T PICTURED	



Detection Line Parts List

ITEM NUMBER	PART NUMBER	DESCRIPTION
*	200005	Firetrace Detection/Actuation Tubing (by the foot)
*	200125	Tube Union With Spring Tops
1	200126	Tube Tee With Spring Tops
*	200136	Bulkhead With Spring Tops
3	200155	Tube Elbow With Spring Tops
*	200160	Spring Top
*	200158	Tube Union Slip On Fitting
2	200157	Tube Tee Slip On Fitting
4	200178	Tube Elbow Slip On Fitting
*	200179	Tube to Threads Union Slip On Fitting
*	200177	Tube to Threads Tee Slip On Fitting
*	200159	Tube to Threads Elbow Slip On Fitting
*	200133	Tube Plug
*	200168	End Of Line Adapter With Spring Top
*	200169	In Line Adapter With Spring Tops
*	310303	Plug With O-Ring For End Of Line Adapter
*	400029	CO ₂ 195 psi Pressure Gauge
*	400004	Pressure Switch With Washer for End Of Line Adapter
*	600090	Audible Alarm (Battery Operated)
*	200171	Mounting Tabs (Qty. 12)
*	200150	Rubber Grommets (Qty. 2)
*	200151	Plastic Grommets (Qty. 2)
* PART NO	T PICTURED	



Component Drawings

Firetrace Indirect High Pressure (IHP) Valve P/N 310201



VALVE		DIMENSION	S (INCHES)			DIMENSIONS	S (METERS)	
	A	В	С	D	А	В	С	D
C05	6.625	5	1.125-12 UNF-2A	G 3/8	0.168	0.127	1.125-12 UNF-2A	G 3/8

Firetrace IHP System Overview



Firetrace Tubing Placement Diagram



MAXIMUM HEIGHT TUBING LAYDUT

Side View

MAXIMUM AREA TUBING LAYOUT

Overhead View

Maximum Length: 120ft Maximum Height Between Layers: 3.28ft Maximum Distance Between Passes: 21.12in



Option #1

- 1. Check to see that the ball valve lever is set to the "ON" position.
- 2. Remove the ON/OFF faceplate.
- 3. Pull the tie through the hole in the ball valve lever.
- 4. Wrap the tie around the ball valve assembly.
- 5. Firmly pull on the tie to tighten and secure the lever.
- 6. If desired, cut off the excess tie.

Option #2

- 1. Remove the ON/OFF faceplate.
- 2. Unscrew the ball valve lever from the assembly.
- 3. Pull the lever off of the ball valve assembly.
- 4. Keep the items in a bag and secure them to the unit.

FM APPROVAL GUIDE LISTING

Model IHP Pre-Engineered, Automatic Indirect High Pressure Carbon Dioxide Detection and Extinguishing Systems

System Designation:	Model IHP Pre-Engineered, Automatic Indirect High Pressure Carbon Dioxide Detection and Extinguishing Systems
System Type:	Pre-Engineered Total Flooding System for the Protection of Class B (Ignitable Liquid) Hazards
Agent Identification:	Carbon Dioxide (CO ₂)
	IHP-500 (5 lb CO ₂)
Available Agent Container Models (Agent Mass):	IHP-1000 (10 lb CO ₂)
(Agent Mass).	IHP-2000 (20 lb CO ₂)
Minimum Design Concentration	34%
Ambient Temperature Installation Range:	0°F to 130°F (-18°C to 54°C)
Maximum Equivalent Length of Discharge Piping:	24 ft (7.3 m)
	IHP-500: Up to 70 ft ³ (2.0 m ³)
Protected Volume*:	IHP-1000: 71 ft ³ to 140 ft ³ (2.0 m ³ to 4.0 m ³)
	IHP-2000: 141 ft ³ to 300 ft ³ (4.0 m ³ to 8.5 m ³)**
Design, Installation, Operation, and Maintenance Manual:	Design, Installation, Operation, and Maintenance Manual for Carbon Dioxide Detection and Extinguishing Systems, P/N 800024, July 2013
Limitations or Exceptions to the Approval:	 * Carbon Dioxide design concentration of 34% at maximum protected volume ** At least one dimension (length, width, or height) must not exceed 2 ft (0.6 m) Further limitations as defined in the most recent version of NFPA 12, as well as in the manual listed above
	Firetrace International LLC 8435 N. 90th Street, Suite 2 Scottsdale, AZ 85258 USA
Approved Filling Stations:	Firetrace International LLC 12 Fairlawn Enterprise Park Bonehurst Rd, Salfords Redhill, Surrey RH1 5GH United Kingdom

APPENDIX B

Safety Data Sheet

Carbon Dioxide



Carbon dioxide

Safety Data Sheet P-4574 This SDS conforms to U.S. Code of Federal Regulations 29 CFR 1910.1200, Hazard Communication. Making our planet more productive" Date of issue: 01/01/1980 Revision date: 07/19/2016 Supersedes: 05/01/2015

SECTION: 1. Product and company i	dentification
1.1. Product identifier	
Product form	: Substance
Name	: Carbon dioxide
CAS No	: 124-38-9
Formula	: CO2
Other means of identification	: Medipure® Carbon Dioxide, Extendapak® EX-2, Refrigerant gas R744, carbonic anhydride,
	carbonic acid gas
	tance or mixture and uses advised against
Jse of the substance/mixture	: Industrial use. Use as directed.
.3. Details of the supplier of the safety d	lata sheet
	Praxair, Inc. 39 Old Ridgebury Road Danbury, CT 06810-5113 - USA T 1-800-772-9247 (1-800-PRAXAIR) - F 1-716-879-2146 <u>www.praxair.com</u>
1.4. Emergency telephone number	
Emergency number	: Onsite Emergency: 1-800-645-4633
	CHEMTREC, 24hr/day 7days/week — Within USA: 1-800-424-9300, Outside USA: 001-703-527-3887 (collect calls accepted, Contract 17729)
SECTION 2: Hazard identification	
2.1. Classification of the substance or mi	ixture
GHS-US classification Liquefied gas H280	
2.2. Label elements	
GHS-US labeling Hazard pictograms (GHS-US)	: GHS04
Signal word (GHS-US)	: WARNING
Hazard statements (GHS-US)	: WARNING : H280 - CONTAINS GAS UNDER PRESSURE; MAY EXPLODE IF HEATED OSHA-H01 - MAY DISPLACE OXYGEN AND CAUSE RAPID SUFFOCATION CGA-HG01 - MAY CAUSE FROSTBITE CGA-HG03 - MAY INCREASE RESPIRATION AND HEART RATE
Precautionary statements (GHS-US)	 P202 - Do not handle until all safety precautions have been read and understood P261 - Avoid breathing gas P262 - Do not get in eyes, on skin, or on clothing P271+P403 - Use and store only outdoors or in a well-ventilated place CGA-PG05 - Use a back flow preventive device in the piping CGA-PG06 - Close valve after each use and when empty CGA-PG02 - Protect from sunlight when ambient temperature exceeds 52°C (125°F)

EN (English US)

SDS ID: P-4574

1/9

	Carbon dioxide
IPRAXAIR	Safety Data Sheet P-4574
Making our planet more productive [*]	This SDS conforms to U.S. Code of Federal Regulations 29 CFR 1910.1200, Hazard Communication.
	Date of issue: 01/01/1980 Revision date: 07/19/2016 Supersedes: 05/01/2015
2.3. Other hazards	
Other hazards not contributing to the classification	: Asphyxiant in high concentrations
	Contact with liquid may cause cold burns/frostbite
	WARNING: Concentration levels of carbon dioxide above about 1 percent are dangerous. Praxair recommends continuous monitoring with alarms to indicate unsafe conditions before and during potential personnel exposure. Use appropriate monitoring device to ensure a safe oxygen level (minimum of 19.5 percent) and a safe carbon dioxide level.
2.4. Unknown acute toxicity (GH	
	No data available
SECTION 3: Composition/Info	rmation on ingredients
3.1. Substance	
Name	: Carbon dioxide
CAS No	: 124-38-9
Name	Product identifier %
Carbon dioxide	(CAS No) 124-38-9 99.5 - 100
3.2. Mixture	
Not applicable	
SECTION 4: First aid measure	25
4.1. Description of first aid meas	
First-aid measures after inhalation	: Remove to fresh air and keep at rest in a position comfortable for breathing If not breathing,
	give artificial respiration, with supplemental oxygen given by qualified personnel. If breathing difficult, qualified personnel should give oxygen. Call a physician.
First-aid measures after skin contact	MAY CAUSE FROSTBITE. For exposure to liquid, cold vapor, or solid carbon dioxide (dry ice immediately warm frostbite area with warm water not to exceed 41°C (105°F). Water temperature should be tolerable to normal skin. Maintain skin warming for at least 15 minutes or until normal coloring and sensation have returned to the affected area. In case of massive exposure, remove clothing while showering with warm water. Seek medical evaluation and treatment as soon as possible.
First-aid measures after eye contact	Immediately flush eyes thoroughly with water for at least 15 minutes. Hold the eyelids open ar away from the eyeballs to ensure that all surfaces are flushed thoroughly. Contact an ophthalmologist immediately.
First-aid measures after ingestion	: Ingestion is not considered a potential route of exposure.
4.2. Most important symptoms a	and effects, both acute and delayed
	No additional information available
	e medical attention and special treatment needed
None.	
SECTION 5: Firefighting meas	sures
5.1. Extinguishing media	
	: Use extinguishing media appropriate for surrounding fire.
Suitable extinguishing media	 An and the second s
Suitable extinguishing media 5.2. Special hazards arising from	

EN (English US)

SDS ID: P-4574

2/9

Making	g our planet more productive	Carbon dioxide Safety Data Sheet P-4574 This SDS conforms to U.S. Code of Federal Regulations 29 CFR 1910.1200, Hazard Communication. Date of issue: 01/01/1980 Revision date: 07/19/2016 Supersedes: 05/01/2015
5.3.	Advice for firefighters	
Firefigh	ting instructions	: WARNING! Liquid and gas under pressure.
Other in	ofrmation	Evacuate all personnel from the danger area. Use self-contained breathing apparatus (SCBA) and protective clothing. Immediately cool containers with water from maximum distance. Stop flow of gas if safe to do so, while continuing cooling water spray. Remove ignition sources if safe to do so. Remove containers from area of fire if safe to do so. On-site fire brigades must comply with OSHA 29 CFR 1910.156 and applicable standards under 29 CFR 1910 Subpart L—Fire Protection. Containers are equipped with a pressure relief device. (Exceptions may exist where authorized by DOT [U.S.] or TC [Canada].).
SECT	ION C. Assidental values	
	ION 6: Accidental releas	
<mark>6.1.</mark> Genera	l measures	ective equipment and emergency procedures : WARNING! Liquid and gas under pressure Rapid release of gaseous carbon dioxide through a pressure relief device (PRD) or valve can result in the formation of dry ice, which is very cold and can cause frostbite
6.1.1.	For non-emergency person	inel
	Series Parada	No additional information available
6.1.2.	For emergency responders	
		No additional information available
6.2.	Environmental precautions	ý l
		Try to stop release.
6.3.	Methods and material for c	ontainment and cleaning up
For con	tainment	Prevent waste from contaminating the surrounding environment. Discard any product, residue, disposable container, or liner in an environmentally acceptable manner, in full compliance with federal, provincial, and local regulations. If necessary, call your local supplier for assistance.
6.4.	Reference to other sections	
		See also sections 8 and 13.
	ION 7: Handling and sto	
7.1. Drecaut	Precautions for safe handli tions for safe handling	ing : Avoid breathing gas
ricodda		Do not get in eyes, on skin, or on clothing
		This gas is heavier than air and in an enclosed space tends to accumulate near the floor, displacing air and pushing it upward. This creates an oxygen-deficient atmosphere near the floor. Ventilate space before entry. Verify sufficient oxygen concentration
		WARNING: Concentration levels of carbon dioxide above about 1 percent are dangerous. Praxair recommends continuous monitoring with alarms to indicate unsafe conditions before and during potential personnel exposure. Use appropriate monitoring devices to ensure a safe oxygen level (minimum of 19.5 percent) and a safe carbon dioxide level
		Wear leather safety gloves and safety shoes when handling cylinders. Protect cylinders from physical damage; do not drag, roll, slide or drop. While moving cylinder, always keep in place removable valve cover. Never attempt to lift a cylinder by its cap; the cap is intended solely to protect the valve. When moving cylinders, even for short distances, use a cart (trolley, hand truck, etc.) designed to transport cylinders. Never insert an object (e.g, wrench, screwdriver, pry bar) into cap openings; doing so may damage the valve and cause a leak. Use an adjustable strap wrench to remove over-tight or rusted caps. Slowly open the valve. If the valve is hard to open, discontinue use and contact your supplier. Close the container valve after each use; keep closed even when empty. Never apply flame or localized heat directly to any part of the container. High temperatures may damage the container and could cause the pressure relief

EN (English US)

SDS ID: P-4574

3/9



Carbon dioxide Safety Data Sheet P-4574

This SDS conforms to U.S. Code of Federal Regulations 29 CFR 1910.1200, Hazard Communication. Making our planet more productive* Date of issue: 01/01/1980 Revision date: 07/19/2016 Supersedes: 05/01/2015

7.2. Conditions for safe storage, including any incompatibilities

Store in a cool, well-ventilated place. Store and use with adequate ventilation. Store only where temperature will not exceed 125°F (52°C). Firmly secure containers upright to keep them from falling or being knocked over. Install valve protection cap, if provided, firmly in place by hand. Store full and empty containers separately. Use a first-in, first-out inventory system to prevent storing full containers for long periods

This gas is heavier than air and in an enclosed space tends to accumulate near the floor, displacing air and pushing it upward. This creates an oxygen-deficient atmosphere near the floor. Ventilate space before entry. Verify sufficient oxygen concentration.

7.3. Specific end use(s)

Storage conditions

None.

1. Control para	meters		
Carbon dioxide (124	-38-9)		
ACGIH	ACGIH TLV-TWA (ppm)	5000 ppm	
ACGIH	ACGIH TLV-STEL (ppm)	30000 ppm	
USA OSHA	OSHA PEL (TWA) (mg/m ³)	9000 mg/m ³	
USA OSHA	OSHA PEL (TWA) (ppm)	5000 ppm	
USA IDLH	US IDLH (ppm)	40000 ppm	
ACGIH	Not established		
USA OSHA	Not established		
Carbon dioxide (124	-38-9)		
ACGIH	ACGIH TLV-TWA (ppm)	5000 ppm	
ACGIH	ACGIH TLV-STEL (ppm)	30000 ppm	
USA OSHA	OSHA PEL (TWA) (mg/m ³)	9000 mg/m³	
USA OSHA	OSHA PEL (TWA) (ppm)	5000 ppm	

Exposure controls 8.2.

Appropriate engineering controls	: Use a local exhaust system with sufficient flow velocity to maintain an adequate supply of air the worker's breathing zone. Mechanical (general): General exhaust ventilation may be acceptable if it can maintain an adequate supply of air. WARNING: Concentration levels of carbon dioxide above about 1 percent are dangerous. Praxair recommends continuous monitoring with alarms to indicate unsafe conditions before and during potential personnel exposure. Use appropriate monitoring devices to ensure a safe oxygen level (minimum of 19 percent) and a safe carbon dioxide level.	
Materials for protective clothing	Wear work gloves and metatarsal shoes for cylinder handling. Protective equipment where needed. Select in accordance with OSHA 29 CFR 1910.132, 1910.136, and 1910.138.	
Eye protection	: Wear safety glasses when handling cylinders; vapor-proof goggles and a face shield during cylinder changeout or whenever contact with product is possible. Select eye protection in accordance with OSHA 29 CFR 1910.133.	
Skin and body protection	As needed for welding, wear hand, head, and body protection to help prevent injury from radiation and sparks. (See ANSI Z49.1.) At a minimum, this includes welder's gloves and protective goggles, and may include arm protectors, aprons, hats, and shoulder protection as well as substantial clothing.	
Respiratory protection	When workplace conditions warrant respirator use, follow a respiratory protection program th meets OSHA 29 CFR 1910.134, ANSI Z88.2, or MSHA 30 CFR 72.710 (where applicable). Use an air-supplied or air-purifying cartridge if the action level is exceeded. Ensure that the respirator has the appropriate protection factor for the exposure level. If cartridge type respirators are used, the cartridge must be appropriate for the chemical exposure. For emergencies or instances with unknown exposure levels, use a self-contained breathing apparatus (SCBA).	at
Thermal hazard protection	: Wear cold insulating gloves when transfilling or breaking transfer connections.	
EN (English US)	SDS ID: P-4574	4/9

EN (English US)



Making our planet more productive

 Safety Data Sheet P-4574

 This SDS conforms to U.S. Code of Federal Regulations 29 CFR 1910.1200, Hazard Communication.

 Date of issue: 01/01/1980
 Revision date: 07/19/2016
 Supersedes: 05/01/2015

0.1. Information on basic physical and	chemical properties
Physical state	: Gas
Appearance	: Colorless gas.
Aolecular mass	: 44 g/mol
Color	: Colorless.
Ddor	: Odorless.
Ddor threshold	: No data available
	: 3.7 (carbonic acid)
Relative evaporation rate (butyl acetate=1)	: No data available
Relative evaporation rate (ether=1)	: Not applicable.
Aelting point	: No data available
Freezing point	: No data available
Boiling point	: -78.5 °C (-109.3°F)
lash point	: No data available
Critical temperature	: 31 °C (87.7°F)
Auto-ignition temperature	: No data available
Decomposition temperature	: No data available
Tammability (solid, gas)	: No data available
/apor pressure	: 57.3 bar (831 psig)
Critical pressure	: 73.7 bar (1069 psig)
Relative vapor density at 20 °C	: 762
Relative density	: 1.22
Relative gas density	: 1.52
Solubility	: Water: 2000 mg/l Completely soluble.
.og Pow	: 0.83
.og Kow	: Not applicable.
/iscosity, kinematic	: Not applicable.
/iscosity, dynamic	: Not applicable.
Explosive properties	Not applicable.
Dxidizing properties	: None.
Explosion limits	: No data available
0.2. Other information	
Gas group Additional information	: Liquefied gas : Gas/vapor heavier than air. May accumulate in confined spaces, particularly at or below ground level

EN (En	alish US)	SDS ID: P-4574	5/9
		Alkali metals, Alkaline earth metals, Acetylide forming metals, Chromium, Titanium > 1022°F (550°C), Uranium (U) > 1382°F (750°C), Magnesium > 1427°F (775°C).	
10.5.	Incompatible materials		
		None under recommended storage and handling conditions (see section 7).	
10.4.	Conditions to avoid		
		None.	
10.3.	Possibility of hazardous reactions		
		Stable under normal conditions.	
10.2.	Chemical stability		
		No reactivity hazard other than the effects described in sub-sections below.	
10.1.	Reactivity		



Making our planet more productive"

Safety Data Sheet P-4574 This SDS conforms to U.S. Code of Federal Regulations 29 CFR 1910.1200, Hazard Communication. Supersedes: 05/01/2015

Date of issue: 01/01/1980 Revision date: 07/19/2016

10.6. Hazardous decomposition products

Electrical discharges and high temperatures decompose carbon dioxide into carbon monoxide and oxygen. The welding process may generate hazardous fumes and gases.

SECTION 11: Toxicological information 11.1. Information on toxicological effects : Not classified Acute toxicity : Not classified Skin corrosion/irritation pH: 3.7 (carbonic acid) Serious eye damage/irritation : Not classified pH: 3.7 (carbonic acid) Respiratory or skin sensitization : Not classified Germ cell mutagenicity : Not classified Carcinogenicity : Not classified Reproductive toxicity : Not classified Specific target organ toxicity (single exposure) : Not classified Specific target organ toxicity (repeated : Not classified exposure) Aspiration hazard : Not classified SECTION 12: Ecological information 12.1. Toxicity Ecology - general : No ecological damage caused by this product. 12.2. Persistence and degradability Carbon dioxide (124-38-9) Persistence and degradability No ecological damage caused by this product. Carbon dioxide (124-38-9) Persistence and degradability No ecological damage caused by this product. 12.3. Bioaccumulative potential Carbon dioxide (124-38-9) BCE fish 1 (no bioaccumulation) Log Pow 0.83 Not applicable. Log Kow Bioaccumulative potential No ecological damage caused by this product. Carbon dioxide (124-38-9) BCF fish 1 (no bioaccumulation) Log Pow 0.83 Not applicable. Log Kow Bioaccumulative potential No ecological damage caused by this product. 12.4. Mobility in soil Carbon dioxide (124-38-9) Mobility in soil No data available Ecology - soil No ecological damage caused by this product. Carbon dioxide (124-38-9) Mobility in soil No data available. Ecology - soil No ecological damage caused by this product.

EN (English US)

SDS ID: P-4574

6/9



Making our planet more productive"

Safety Data Sheet P-4574 e* This SDS conforms to U.S. Code of Federal Regulations 29 CFR 1910.1200, Hazard Communication. Date of issue: 01/01/1980 Revision date: 07/19/2016 Supersedes: 05/01/2015

Date	e of issue: 01/01/1980 Revision date: 07/19/2016 Supersedes: 05/01/2015			
12.5. Other adverse effects				
Effect on ozone layer	: None			
Global warming potential [CO2=1]	: 1			
Effect on the global warming	: When discharged in large quantities may contribute to the greenhouse effect			
n na				
SECTION 13: Disposal considera	tions			
13.1. Waste treatment methods				
Waste treatment methods	May be vented to atmosphere in a well ventilated place. Discharge to atmosphere in large quantities should be avoided. Do not discharge into any place where its accumulation could be dangerous. Contact supplier if guidance is required.			
Waste disposal recommendations	: Do not attempt to dispose of residual or unused quantities. Return container to supplier.			
SECTION 14: Transport informati	on			
n accordance with DOT				
Transport document description	: UN1013 Carbon dioxide, 2.2			
UN-No.(DOT)	: UN1013			
Proper Shipping Name (DOT)	: Carbon dioxide			
Class (DOT)	2.2 - Class 2.2 - Non-flammable compressed gas 49 CFR 173.115			
Hazard labels (DOT)	: 2.2 - Non-flammable gas			
Additional information				
Emergency Response Guide (ERG) Number	120			
Other information	: No supplementary information available.			
Special transport precautions	Avoid transport on vehicles where the load space is not separated from the driver's compartment. Ensure vehicle driver is aware of the potential hazards of the load and knows what to do in the event of an accident or an emergency. Before transporting product containers: - Ensure there is adequate ventilation Ensure that containers are firmly secured Ensure cylinder valve is closed and not leaking Ensure valve outlet cap nut or plug (where provided) is correctly fitted Ensure valve protection device (where provided) is correctly fitted.			
Transport by sea				
JN-No. (IMDG)	: 1013			
Proper Shipping Name (IMDG)	: CARBON DIOXIDE			
Class (IMDG)	: 2 - Gases			
/FAG-No	: 120			
5				
Air transport				
JN-No. (IATA)	: 1013			
Proper Shipping Name (IATA)	: Carbon dioxide			
Class (IATA)	: 2			
Civil Aeronautics Law	: Gases under pressure/Gases nonflammable nontoxic under pressure			
SECTION 15: Regulatory information	tion			
15.1. US Federal regulations				
Carbon dioxide (124-38-9)				
Listed on the United States TSCA (Toxic S	ubstances Control Act) inventory			
SARA Section 311/312 Hazard Classes	Immediate (acute) health hazard Sudden release of pressure hazard			
EN (English US)	SDS ID: P-4574 7/			



Making our planet more productive"

This SDS conforms to U.S. Code of Federal Regulations 29 CFR 1910.1200, Hazard Communication. Date of issue: 01/01/1980 Revision date: 07/19/2016 Supersedes: 05/01/2015

15.2. International regulations

CANADA

Carbon dioxide (124-38-9)

Listed on the Canadian DSL (Domestic Substances List)

Carbon dioxide (124-38-9)

Listed on the Canadian DSL (Domestic Substances List)

EU-Regulations

Carbon dioxide (124-38-9)

Listed on the EEC inventory EINECS (European Inventory of Existing Commercial Chemical Substances)

15.2.2. National regulations

- Carbon dioxide (124-38-9)
- Listed on the AICS (Australian Inventory of Chemical Substances) Listed on IECSC (Inventory of Existing Chemical Substances Produced or Imported in China)
- Listed on the Japanese ENCS (Existing & New Chemical Substances) inventory
- Listed on the Korean ECL (Existing Chemicals List) Listed on NZIoC (New Zealand Inventory of Chemicals)
- Listed on PICCS (Philippines Inventory of Chemicals and Chemical Substances)
- Listed on the Canadian IDL (Ingredient Disclosure List) Listed on INSQ (Mexican national Inventory of Chemical Substances) Listed on CICR (Turkish Inventory and Control of Chemicals)

-	10170	-	1000		North Contraction
1	5.3.	US	State	reau	lations

15.5. OO Grate regulations	
Carbon dioxide(124-38-9)	
U.S California - Proposition 65 - Carcinogens List	No
U.S California - Proposition 65 - Developmental Toxicity	No
U.S California - Proposition 65 - Reproductive Toxicity - Female	No
U.S California - Proposition 65 - Reproductive Toxicity - Male	No
State or local regulations	U.S Massachusetts - Right To Know List U.S New Jersey - Right to Know Hazardous Substance List U.S Pennsylvania - RTK (Right to Know) List

U.S California - Proposition 65 - Carcinogens List	U.S California - Proposition 65 - Developmental Toxicity	U.S California - Proposition 65 - Reproductive Toxicity - Female	U.S California - Proposition 65 - Reproductive Toxicity - Male	Non-significant risk level (NSRL)
No	No	No	No	
Carbon dioxide (124-3	8-9)			
U.S Massachusetts - U.S New Jersey - Rig U.S Pennsylvania - R	ht to Know Hazardous Substance	List		

EN (English US)

SDS ID: P-4574

8/9



Making our planet more productive"

Safety Data Sheet P-4574 This SDS conforms to U.S. Code of Federal Regulations 29 CFR 1910.1200, Hazard Communication.

Date of issue: 01/01/1980 Revision date: 07/19/2016 Supersedes: 05/01/2015

SECTION 16: Other information Other information When you mix two or more chemicals, you can create additional, unexpected hazards. Obtain and evaluate the safety information for each component before you produce the mixture. Consult an industrial hygienist or other trained person when you evaluate the end product. Before using any plastics, confirm their compatibility with this product Fumes and gases produced during welding and cutting processes can be dangerous to your health and may cause serious lung disease. KEEP YOUR HEAD OUT OF FUMES. DO NOT BREATHE FUMES AND GASES. Use enough ventilation, local exhaust, or both to keep fumes and gases from your breathing zone and the general area. Short-term overexposure to fumes may cause dizziness, nausea, and dryness or irritation of the nose, throat, and eyes; or may cause other similar discomfort. Contaminants in the air may add to the hazard of fumes and gases. One such contaminant, chlorinated hydrocarbon vapors from cleaning and degreasing activities, poses a special risk. DO NOT USÉ ELECTRIC ARCS IN THE PRESENCE OF CHLORINATED HYDROCARBON VAPORS-HIGHLY TOXIC PHOSGENE MAY BE CHLORINATED HYDROCARBON VAPORS—HIGHLY TOXIC PHOSGENE MAY BE PRODUCED. Metal coatings such as paint, plating, or galvanizing may generate harmful fumes when heated. Residues from cleaning materials may also be harmful. AVOID ARC OPERATIONS ON PARTS WITH PHOSPHATE RESIDUES (ANTI-RUST, CLEANING PREPARATIONS)—HIGHLY TOXIC PHOSPHINE MAY BE PRODUCED The opinions expressed herein are those of qualified experts within Praxair, Inc. We believe that the information contained herein is current as of the date of this Safety Data Sheet. Since the use of this information and the conditions of use are not within the control of Praxair, Inc, it is the user's obligation to determine the conditions of safe use of the product Praxair SDSs are furnished on sale or delivery by Praxair or the independent distributors and suppliers who package and sell our products. To obtain current SDSs for these products, contact your Praxair sales representative, local distributor, or supplier, or download from www.praxair.com. If you have questions regarding Praxair SDSs, would like the document number and date of the latest SDS, or would like the names of the Praxair suppliers in your area, phone or write the Praxair Call Center (Phone: 1-800-PRAXAIR/1-800-772-9247 Address: Praxair Call Center, Praxair, Inc. P.O. Box 44, Tonawanda, NY 14151-0044) Praxair asks users of this product to study this SDS and become aware of the product hazards and safety information. To promote safe use of this product, a user should (1) notify employees, agents, and contractors of the information in this SDS and of any other known product hazards and safety information, (2) furnish this information to each purchaser of the product, and (3) ask each purchaser to notify its employees and customers of the product hazards and safety information PRAXAIR, the Flowing Airstream design, Medipure, and the Medipure design are trademarks or registered trademarks of Praxair Technology, Inc. in the United States and/or other countries. NFPA health hazard : 2 - Intense or continued exposure could cause temporary incapacitation or possible residual injury unless prompt medical attention is given. NFPA fire hazard : 0 - Materials that will not burn NFPA reactivity : 0 - Normally stable, even under fire exposure conditions, and are not reactive with water. SA NFPA specific hazard : SA - This denotes gases which are simple asphyxiants. **HMIS III Rating** : 1 Slight Hazard - Irritation or minor reversible injury possible Health Flammability : 0 Minimal Hazard Physical : 3 Serious Hazard SDS US (GHS HazCom 2012) - Praxair This information is based on our current knowledge and is intended to describe the product for the purposes of health, safety and environmental requirements only. It should not therefore be construed as guaranteeing any specific property of the product. EN (English US) SDS ID: P-4574 9/9