



DESIGN, INSTALLATION, OPERATION, AND MAINTENANCE MANUAL

FOR

**CLEAN AGENT SELF CONTAINED AUTOMATIC FIRE EXTINGUISHER
UNITS**

DESIGNED FOR USE WITH:

CARBON DIOXIDE FIRE PROTECTION AGENT

950504 - 5LB
951004 - 10LB
952004 - 20LB
953504 - 35LB
955004 - 50LB

Document: 800058 (DIOM, IHP, DOT, CO2, 838 PSI)

**Firetrace International, LLC
8435 N. 90TH St, Suite 2
Scottsdale, AZ 85258 USA**

Telephone: 480-607-1218
Fax: 480-315-1316
www.firetrace.com

TABLE OF CONTENTS

1.0	FORWARD	4
1.1	General	4
1.2	Safety Precautions	4
2.0	INTRODUCTION	6
2.1	Carbon Dioxide Extinguishing Agent	6
2.1.1	Cleanliness	6
2.1.2	Physical Properties of Carbon Dioxide	6
2.1.3	Fill Density	7
3.0	SYSTEM DESCRIPTION.....	8
3.1	General	8
3.1.1	Operating Pressure	9
3.1.2	Operating Temperature Range Limitations:	9
3.2	Component Descriptions.....	9
3.2.1	CO2 Cylinder Valve Assemblies	9
3.2.2	Cylinder Mounting Bracket	11
3.2.3	Firetrace Flexible Detector/Actuation Tubing	11
3.2.4	Discharge Nozzle	11
3.2.5	Flexible Hoses and Fittings	11
3.2.6	Pressure Switch	12
3.2.7	Recharge Adapters, CO ₂ Cylinder (600024)	12
3.2.8	Cylinder N2 Recharge Adapter (910600).....	12
3.2.9	CO2 Warning Nameplate	12
4.0	SYSTEM DESIGN AND LIMITATIONS FOR TOTAL FLOODING	12
4.1	General	12
4.2	Design Procedure	12
4.3	Hazard Enclosure Volume Limitations	13
4.4	General Specifications.....	13
4.4.1	Discharge Time:.....	13
4.4.2	Storage and Operating Temperature Range:	13
4.4.3	System Operating Pressure:	13
4.5	Minimum Design Concentrations	14
4.6	Openings and Ventilation Shutdown	15
4.7	CO2 Design Concentration Flooding Factors	15
4.8	Maximum Protected Volume	16
4.8.1	Example Calculations	17
4.9	Nozzle and Discharge Tubing Requirements.....	17
4.9.1	Discharge Nozzle Limitations	17
4.9.2	Discharge Piping & Fitting Specifications.....	18
4.9.3	Maximum Piping and Fitting Limitations	18
4.10	Firetrace Detector Tubing	18
5.0	INSTALLATION INSTRUCTIONS	19
5.1	CO ₂ Cylinder/Valve and Bracket Assemblies	19
5.2	Discharge Piping and Nozzles	20
5.3	Firetrace Detection Tubing	20
5.4	Pressurization of Firetrace Detection Tubing.....	20

6.0	SERVICE, MAINTENANCE, & FILLING INSTRUCTIONS	21
6.1	General	22
6.2	Periodic Service and Maintenance	22
6.3	Periodic Service and Maintenance Procedures	22
6.3.1	Weekly/Monthly Inspection	22
6.3.2	Semi-Annual Inspection	22
6.3.3	Five Year Inspection	23
6.4	Post Fire Maintenance	23
6.4.1	CO2 Cylinder Valve	23
6.5	CO2 Cylinder Retest	23
6.6	Filling Procedures	24
APPENDIX A		25
APPENDIX B		32

1.0 FORWARD

1.1 General

This manual is written for the fire protection professional that designs, installs, and maintains Firetrace Pre-engineered Automatic High-Pressure Carbon Dioxide (CO₂) Extinguisher Units.

Firetrace CO₂ automatic high-pressure extinguisher units are to be designed, installed, inspected, tested, maintained, and recharged by qualified trained personnel in accordance with the following:

All instructions, limitations, etc. contained in this manual P/N 800058

All information contained on the agent cylinder nameplate(s).

NFPA 12, *Standard on Carbon Dioxide Extinguishing Systems 2018 Edition*.

Local Authority having jurisdiction.

1.2 Safety Precautions

Safety precautions are essential when any electrical or mechanical equipment is involved. These precautions should be followed when handling, servicing, and recharging Firetrace CO₂ automatic high-pressure extinguisher unit cylinders and equipment. If safety precautions are overlooked or ignored, personal injury or property damage may occur.

The following symbols are used throughout this manual. Always heed these precautions. They are essential to the safe use of the equipment described in this manual.

DANGER:

This danger symbol identifies immediate hazards and provides specific instructions or procedures, which, if not correctly followed **WILL** result in severe personal injury or death.

WARNING:

This warning symbol identifies specific instructions or procedures, which, if not correctly followed, **COULD** result in severe personal injury or death.

CAUTION:

This caution symbol identifies specific instructions or procedures, which, if not correctly followed, **COULD** result in minor personal injury or equipment or property damage.

The following safety precautions should always be followed:

 WARNING

Pressurized (charged) cylinders are extremely hazardous and if not handled properly are capable of causing bodily injury, death or property damage.

1. Read and understand this manual and the other documents referenced herein.
2. The valve discharge outlet safety cap and filling port cap **MUST** be installed on the cylinder valve at all times and only removed when connected into the discharge tubing, or when performing testing, or salvaging operations in accordance with the procedures contained in this manual.
3. Wear safety glasses when working with pressurized cylinders and charging equipment. It is recommended to wear leather gloves to avoid any cryogenic burns if CO₂ is accidentally discharged on or near the skin.
4. Make sure that the ball valve (attached to the cylinder valve) is closed (lever is in "OFF" position), safety caps installed and the detection tubing has been removed from the cylinder valve before removing the cylinder from the installation, and before performing any charging, leak tests or salvage operations.
5. Follow all the safety procedures included on the cylinder nameplate and in this manual.
6. Never assume that a cylinder is empty. Treat all cylinders as if they are fully charged.

Any questions concerning the information contained in this manual should be addressed to:

Firetrace USA LLC.

8435 N. 90th Street, Suite 2
Scottsdale, AZ 85258 USA

Telephone: 480-607-1218

The following web site should be visited for frequent technical announcements

www.firetrace.com

2.0 INTRODUCTION

The following Firetrace High Pressure CO₂ Automatic Fire Extinguisher Units are covered in this manual:

950504 - CYLINDER ASSEMBLY, DOT, IHP, CO₂, 5LB
951004 - CYLINDER ASSEMBLY, DOT, IHP, CO₂, 10LB
952004 - CYLINDER ASSEMBLY, DOT, IHP, CO₂, 20LB
953504 - CYLINDER ASSEMBLY, DOT, IHP, CO₂, 35LB
955004 - CYLINDER ASSEMBLY, DOT, IHP, CO₂, 50LB

These units are designed for total flooding using CO₂, in accordance with NFPA 12, *Standard on Carbon Dioxide Extinguishing Systems: 2018 Edition*

Each installed pre-engineered unit is equipped with its' own detection and its own discharge tubing and nozzles. The pre-engineered concept minimizes the amount of engineering involved in the unit's design. When the discharge tubing and nozzles are installed within the limitations stated in this manual, no hydraulic calculations are required to determine pressure drop, agent flow or discharge time.

The hazard being protected can be any size, shape or volume, provided that the hazard being protected is within the limitations described in this Manual. Each extinguisher unit, when installed, is a self-contained unit, meaning that it is equipped with its own automatic (non-electric) detection system, which when actuated, automatically releases the suppression agent into the hazard area.

Local authorities having jurisdiction should be consulted as to the acceptability for particular hazards and requirements covering installation.

2.1 Carbon Dioxide Extinguishing Agent

The extinguishing agent used in Firetrace pre-engineered automatic high-pressure extinguisher units is Carbon Dioxide, more commonly known as CO₂. CO₂ is a colorless, odorless, electrically nonconductive inert gas that is an extremely effective fire suppression agent.

2.1.1 Cleanliness

CO₂ is clean and leaves no residue, thereby minimizing any after fire clean up, along with keeping expensive downtime to a minimum. Most materials such as steel, aluminum, stainless steel, brass, as well as plastics, rubber and electronic components are not affected by exposure to CO₂. This agent is also environmentally friendly, having an ozone depletion potential (ODP) of 0.00.

2.1.2 Physical Properties of Carbon Dioxide

Chemical Name: Carbon Dioxide

Molecular Weight	44.01
Boiling Point (°F) @ 14.7psia	-109.3
Freezing Point (°F)	-69.9
Critical Temperature (°F)	87.9
Critical Pressure (psia)	1071

Critical Density (lbm/ft ³)	29.2
Specific Heat, Liquid (BTU/Lb-°F) @ 2°F	0.489
Specific Heat, Vapor (BTU/Lb-°F) @ Constant Pressure (1 ATM) @ 77°F	
Heat of Vaporization (BTU/lb) @ Boiling Point	
Thermal Conductivity (BTU/hr ft °F) of Liquid @ 77°F	
Viscosity, Liquid (lb/ft hr) @ 77°F	
Vapor Pressure (psig) @ 70°F	838
Ozone Depletion Potential	0.00

2.1.3 Fill Density

Each Firetrace CO₂ storage cylinder has been designed for a maximum fill density as shown in Table 1. It is important that these values not be exceeded.

Fill density and temperature significantly affect the pressure in the storage cylinder. At elevated temperatures the rate of increase in pressure is very sensitive to fill density (see Figure 1). If the maximum fill density is exceeded; the pressure will increase rapidly with temperature increase so as to present a hazard to personnel and property. Adherence to the limits on fill density and pressurization levels will prevent excessively high pressures from occurring if the storage cylinder is exposed to elevated temperature. This will also minimize the possibility of an inadvertent discharge of agent through the cylinder pressure relief device, where provided. It is recommended to not mount the cylinder in direct sunlight as this would create elevated cylinder temperatures.




Figure 1 - Pressure vs. Temperature of CO₂

3.0 SYSTEM DESCRIPTION

3.1 General

The Firetrace CO₂ Automatic High-Pressure units are available in 5 sizes, namely:

950504 - CYLINDER ASSEMBLY, DOT, IHP, CO₂, 5LB
951004 - CYLINDER ASSEMBLY, DOT, IHP, CO₂, 10LB
952004 - CYLINDER ASSEMBLY, DOT, IHP, CO₂, 20LB
953504 - CYLINDER ASSEMBLY, DOT, IHP, CO₂, 35LB
955004 - CYLINDER ASSEMBLY, DOT, IHP, CO₂, 50LB

These units are designed for use in Total Flooding applications where the hazard is not occupiable by a human being. A lock-out valve shall be provided on all systems except where dimensional constraints prevent personnel from entering the protected space.

The Firetrace CO₂ units can be used, but are not limited, to protect the following:

- Electrical and electronic cabinets.
- Telecommunication areas.
- Data Processing areas and cabinets.
- Other high value assets.
- Laboratory fume /exhaust cabinets
- Pump enclosures
- UPS units
- Flammable Chemicals storage cabinets
- Generator Enclosures
- Transformer Cabinets
- Computer/Data Storage Cabinets
- CNC & VMC Machining centers
- Many other applications

CO₂ is a gaseous fire-extinguishing agent that is effective for use on:

- Class A -
 - Surface type fires
 - Deep seated fires (Total Flood Only)
- Class B - Flammable liquid fires
- Class C - Electrical equipment fires

CO₂ should not be used where the following materials may be present.

Pyrotechnic chemicals containing their own oxygen supply.

Reactive metals such as lithium, sodium, potassium, magnesium, titanium, zirconium, uranium and plutonium.

Metal hydrides.

Chemicals capable of undergoing auto thermal decomposition, such as certain organic peroxides and hydrazine.

For hazards beyond the scope described above, it is recommended that the designer consult with Firetrace, NFPA 12, and the local authority having jurisdiction, as to the suitability on the use of CO₂ for a particular hazard, for personnel exposure effects from the design concentration, and for installation requirements.

Firetrace CO₂ Automatic High-Pressure Extinguisher Units consist of the following major components:

- CO₂ Cylinder/Valve assembly.
- Cylinder Mounting Bracket.
- Firetrace detector/actuation tubing and fittings (No substitute).
- Discharge nozzles.
- Discharge Port Adapter
- Pressure switch (Optional)
- Firetrace Flex Hose (Optional)
- Discharge tubing and fittings (Furnished by others).

Once installed, the Firetrace Automatic High-Pressure Unit becomes a self-contained, self-actuating unit that does not require an external source of power or electricity.

The unit utilizes unique Firetrace flexible tubing that is attached to the cylinder valve. This tubing is pressurized with dry nitrogen to maintain the cylinder valve in the closed position. The tubing is temperature sensitive, and acts as a continuous linear thermal detector that ruptures upon direct flame impingement. Once the detector tubing is ruptured, the cylinder valve automatically opens, allowing the CO₂ agent to flow through the discharge tubing, distributing the extinguishing agent through the nozzle(s) onto the protected area. Upon actuation, the pressure switch can be used to indicate discharge, shutdown ventilation, close all openings, shut-off electrical power, etc. as may be required.

3.1.1 Operating Pressure

The CO₂ cylinder is stored as a liquefied gas under its own pressure; 838psig @ 70°F.

3.1.2 Operating Temperature Range Limitations:

The ambient operating temperature range for all unit components is:
0°F to +130°F (-17.8°C to +54.4°C).

3.2 Component Descriptions

3.2.1 CO₂ Cylinder Valve Assemblies

CO₂ is stored in DOT/TC aluminum cylinders as a liquefied compressed gas, under its own pressure; 838psig @ 70°F (5,778 KPa @ 21°C). The cylinder/valve assemblies are available in 5 sizes, namely:

- 5 LB size filled with 5.0 LBS (2.27 Kg) of CO₂
- 10 LB size; filled with 10.0 LBS (4.54 Kg) of CO₂
- 20 LB size; filled with 20.0 LBS (9.07 Kg) of CO₂
- 35 LB size; filled with 35.0 LBS (15.88 Kg) of CO₂
- 50 LB size; filled with 50.0 LBS (22.68 Kg) of CO₂

Each cylinder is equipped with a brass valve and a quarter turn ball valve that interfaces with the Firetrace detector tubing. The ball valve must be kept closed at all times when the cylinder is not in service.

In addition, the CO₂ Cylinder valves are equipped with a pressure relief (rupture disc) device in compliance with DOT/TC requirements.

Each valve is also equipped with (1) discharge outlet port and (1) filling port. Each port is provided with a safety cap that must be installed whenever a cylinder is not in service. These caps are safety devices designed to prevent uncontrolled discharge of the cylinder in the event that the valve is accidentally actuated.

 WARNING
The safety caps must be installed on the valve discharge port and filling port at all times, except when connected into the units discharge tubing or when filling. Failure to follow these instructions could result in personal injury, death or property damage.

Table 1 describes the cylinder assemblies. Each cylinder is equipped with a straight siphon tube and can only be mounted in a vertical (upright) position.

Nom Size	Cylinder	Outside Dia.		Overall Height		Internal Volume		CO ₂ Agent		Fill Density
	PN	in.	cm	in.	Cm	in ³	cm ³	lb.	kg	%
5	110050	5.25	12.70	20.0	50.67	205	3359	5.0	2.27	68
10	110100	6.89	17.50	22.4	55.32	408	6717	10.0	4.54	68
20	110200	8.00	20.32	29.0	72.14	816	13340	20.0	9.07	68
35	113500	8.00	20.32	42.3	107.44	1429	23417	35.0	15.88	68
50	115000	8.66	22.00	52.0	132.08	2040	33430	50.0	22.68	68

Table 1: CO₂ Cylinders

Table 2 describes the DOT/TC Specifications used for the manufacture of the CO₂ cylinders.

Nominal Size	DOT Spec	TC Spec	Cylinder Service Pressure psig	Test Pressure	
				DOT psig	TC psig
5	3AL1800	3ALM124	1800	3000	2700
10	3AL1800	3ALM124	1800	3000	2700
20	3AL1800	3ALM124	1800	3000	2700
35	3AL1800	3ALM124	1800	3000	2700
50	3AL1800	3ALM124	1800	3000	2700

Table 2: DOT/TC Cylinder Specifications

The Firetrace CO₂ Units are designed for an operating temperature range of 0°F to +130°F. Table 3 shows the cylinder, pressure-temperature relationship based on a maximum fill density of 68%; and a charged pressure of 838 psig at 70°F.

Cylinder Pressure			
Temperature		Pressure	
°F	°C	psig	kPa
32	0.00	505	3,481
40	4.44	567	3,909
50	10.00	652	4,495
60	15.56	747	5,150
70	21.11	852	5,874
80	26.67	975	6,722
90	32.22	1205	8,308
100	37.78	1465	10,100
110	43.33	1725	11,893
120	48.89	1995	13,755
130	54.44	2265	15,616
140	60.00	2545	17,547

Table 3: Cylinder Pressure-Temperature Relationship

3.2.2 Cylinder Mounting Bracket

A wall mounted painted steel bracket is used to mount the 5, 10, and 20lb cylinder/valve assemblies in a vertical (upright) position. Each bracket is equipped with an interlocking steel strap that is secured with a metallic pin.

A wall mounted steel and nylon strap bracket is used to mount the 35 and 50 lb cylinder/valve assemblies in place.

3.2.3 Firetrace Flexible Detector/Actuation Tubing

The Firetrace tubing is used as a combination linear heat detector and unit activation device to cause actuation of the CO₂ agent cylinder. The tubing is installed throughout the hazard volume, with one end connected to the CO₂ cylinder valve. The tubing is pressurized with nitrogen to 195 psig while maintaining the ball valve in the “OFF” position. An optional pressure gauge or pressure switch can be connected to the other end of the detector tube to monitor tubing pressure and/or signal unit actuation etc. The detector tubing is heat sensitive and in a fire situation, is designed to rupture at any point along the tube. The rupture of the tube releases the nitrogen pressure causing the CO₂ cylinder valve to actuate, resulting in complete discharge of the CO₂ agent through the nozzles.

3.2.4 Discharge Nozzle

Discharge nozzles are used to distribute CO₂ agent uniformly throughout the hazard area. One size nozzle is available for use with all IHP models used for total flood applications and must be used within the limitations described in this Manual

3.2.5 Flexible Hoses and Fittings

High pressure Flexible hoses and hose fittings are available as an optional part for the system discharge network, for all system sizes. Flexible hoses and hose fittings shall be in accordance with the latest edition of NFPA 12 or the local authority having jurisdiction. Temperature and pressure rating of the flexible hoses and flexible hose fittings shall not be exceeded.

The flexible hoses are constructed with stainless steel wire braid reinforcement. Both ends are male 1/2in. NPT threads. The flexible hoses have a maximum operating pressure of 2000 psig [137.9 bar] and a minimum bend radius of 5.2 in [13.2 cm]. Refer to Table 9 – Flexible Discharge Hose Specifications for additional information.

3.2.6 Pressure Switch

A pressure switch is available as an optional item. This switch can be connected at the end of the line of the Firetrace detector tubing to detect low system pressure, alert system actuation or to energize/de-energize electrically operated equipment. Firetrace recommends that all units use a pressure switch coupled with some device to alert personnel in the event of discharge.

3.2.7 Recharge Adapters, CO₂ Cylinder (600024)

The recharge adapter is connected to the filling port located on the cylinder valve during the cylinder recharging procedure. The adapter is used for refilling the cylinder with CO₂.

3.2.8 Cylinder N2 Recharge Adapter (910600)

The recharge adapter is connected to the Firetrace tubing, and the other end of the tubing is attached to the ball valve, located on the cylinder valve, during the charging procedure. The adapter is used to apply nitrogen pressure to the detection tubing, and to keep the valve piston seated.

3.2.9 CO₂ Warning Nameplate

The Warning Plate is required to warn personnel not to enter the hazard area during or after discharge. Warning signs shall be provided in a conspicuous location, at the entrance to the protected areas, or in the case of cabinet protection on the front face of the cabinet. Signs must be in accordance with NFPA 12, Section 4.3.

4.0 SYSTEM DESIGN AND LIMITATIONS FOR TOTAL FLOODING

4.1 General

The Firetrace series of CO₂ Pre-Engineered Automatic High-Pressure Extinguisher units were tested and limits established by Firetrace and Factory Mutual. These units were subjected to numerous performance tests, in order to verify their suitability and to establish design limitations for:

- Hazard volume
- Nozzle placement
- Discharge time and flow rates
- Design concentrations & design factors
- Detector tubing placement

The pre-engineered automatic unit concept minimizes the amount of engineering required when evaluating a design for a specific application. So long as the discharge piping, tubing, and nozzles are installed within the limits prescribed in this manual, no calculations are required for pressure drop, flow rates or discharge time. When the additional limitations of hazard volume, design concentration, agent quantity, detector arrangement, etc., are also met, the unit installation can be understood to comply with the design requirements and NFPA 12.

4.2 Design Procedure

The following procedures should be used to design a Firetrace CO₂ pre-engineered IHP automatic extinguisher unit. In addition, the applicable requirements specified in NFPA 12 should be followed.

- a) Conduct a survey and analysis of the hazard to be protected
- b) Determine the height, length, and width of the enclosure. Calculate the volume. All of these parameters must be within the dimensional limits specified in this manual. (See Section 4.3, Table 4).

- c) Determine the anticipated minimum and maximum ambient temperatures expected within the enclosure to be protected.
- d) Determine the minimum design concentration required for the hazard. (See Section 4.5 and Table 6).
- e) Determine the integrity of the enclosure. Are there any openings that must be closed at the time of agent discharge? (See Section 4.6).
- f) Calculate the quantity of CO₂ agent required, with the proper design concentration, to protect the enclosed space. (Refer to Section 4.7 and Example 4.8.1).
- g) Determine the cylinder size required, based on the hazard volume limitations, enclosure size, and quantity of CO₂ agent required.
- h) Determine the location of the CO₂ cylinder.
- i) Determine the location and quantity of nozzles required, based on the size and configuration of the enclosure. (See Section 4.9 and Table 9).
- j) Determine the routing and quantity of discharge pipe (tubing) required. The discharge pipe (tubing) and fitting limitations must not be exceeded. (See Section 4.9 and Table 9).
- k) Determine the arrangement and placement of the Firetrace detector tubing. (See Section 4.10).
- l) Determine any auxiliary equipment requirements, such as pressure switch(s) to sound alarms, shut-down ventilation, shut-off electrical power, etc..
- m) Prepare system drawings, bill of materials list, etc; following Section 4.4 of NFPA 12 2018 Edition.

4.3 Hazard Enclosure Volume Limitations

The maximum volume for each size unit is shown in Table 4. The protected enclosure can be any size or shape provided that the volume does not exceed the limitations shown in Table 4 with the exception of the 952004, 953504 and 955004 as noted below.

Model	CO ₂ (Lbs)	Volume (Ft ³)
950504	5.0	70
951004	10.0	140
952004	20.0	300*
953504	35.0	525*
955004	50.0	750*
* At least one dimension (l, w, h) must not exceed 2 feet Volumes are based on 34% Design Concentration		

Table 4: Enclosure Size Limitations

4.4 General Specifications

4.4.1 Discharge Time:

Surface fires: The design concentration must be achieved within 1 minute from start of discharge.

4.4.2 Storage and Operating Temperature Range:

The Firetrace CO₂ units and equipment are designed to be stored and operated at an ambient temperature range of 0°F to +130°F. (-17.8°C to +54.4°C).

4.4.3 System Operating Pressure:

The normal operating pressure for the unit is 838 psig at 70°F.

4.5 Minimum Design Concentrations

The minimum design concentrations to be used with Firetrace CO₂ units shall not be less than 34%. For class B hazards, proper consideration must be given to the material involved in the hazard, the design concentration should then be given a safety factor (SF) of 20%, as specified in NFPA 12, Year 2018 edition.

Hazard Type	Minimum Safety Factor
Class B Flammable Liquids	20%

Table 5: Minimum Safety Factor

Table 6 lists CO₂ minimum design concentrations that must be used with Firetrace CO₂ units for Class A hazards and the various Class B fuels shown.

Consult Firetrace website, or contact Firetrace if the hazard you desire to protect is not listed.

Material	Theoretical Minimum CO ₂ Concentration %	Minimum Design CO ₂ Concentration %
Class A (surface fires) (a) Including plastic materials typically found in electrical/electronic equip.	34	34
Class B fuels (b)		
Acetylene	55	66
Acetone	27	34
Aviation Gas Grades 115/145	30	36
Benzol, Benzene	31	37
Butadiene	34	41
Butane	28	34
Butane-I	31	37
Carbon Disulfide	60	72
Carbon Monoxide	53	64
Coal or Natural Gas	31	37
Cyclopropane	31	37
Diethyl Ether	33	40
Dimethyl Ether	33	40
Dowtherm	38	46
Ethane	33	40
Ethyl Alcohol	36	43
Ethyl Ether	38	46
Ethylene	41	49
Ethylene Dichloride	21	34
Ethylene Oxide	44	53
Gasoline	28	34
Hexane	29	35
Higher Paraffin Hydrocarbons $C_nH_{2m} + 2m - 5$	28	34
Hydrogen	62	75

Hydrogen Sulfide	30	36
Isobutane	30	36
Isobutylene	26	34
Isobutyl Formate	26	34
JP-4	30	36
Kerosene	28	34
Methane	25	34
Methyl Acetate	29	35
Methyl Alcohol	33	40
Methyl Butene - I	30	36
Methyl Ethyl Ketone	33	40
Methyl Formate	32	39
Pentane	29	35
Propane	30	36
Propylene	30	36
Quench, Lube Oils	28	34
Note: The theoretical minimum extinguishing concentrations in air for the materials in the table were obtained from a compilation of Bureau of Mines, <i>Limits of Flammability of Gases and Vapors</i> (Bulletins 503 and 627)		

Table 6: Minimum Carbon Dioxide Concentrations for Extinguishment

For all materials not given in Table 6, the minimum theoretical carbon dioxide concentration shall be obtained from some recognized source or determined by test.

4.6 Openings and Ventilation Shutdown

Provisions must be made to provide means to close all openings in the hazard enclosure and shut-off ventilation at the time of discharge.

4.7 CO₂ Design Concentration Flooding Factors

The total flooding quantity of CO₂ agent needed to protect an enclosure containing a material requiring a 34% design concentration can be found in Table 7.

To find the total quantity of CO₂ required, multiply the hazard volume by the Volume Factor found in Table 7

If the design concentration is greater than 34%, the basic quantity calculated from Table 7 shall be multiplied by the corresponding conversion factor found in Figure 2.

CAUTION

This table should only be used for materials requiring a 34% CO₂ Design Concentration. And for environments where the temperature range is between 0-130 ° F

(A) Volume of Space (Ft ³)	(B) Volume Factor		(C) Calculated Quantity (LB) (Not Less Than)
	Ft ³ /lb CO ₂	lb CO ₂ /Ft ³	
Up to 140	14	0.072	---
141-500	15	0.067	10
501-1600	16	0.063	35
1601-4500	18	0.056	100
4501-50,000	20	0.050	250
Over 50,000	22	0.046	2500

Table 7: Flooding Factors for 34% Concentration.




Figure 2 - Conversion Factor for Design Concentrations Greater than 34%.

4.8 Maximum Protected Volume

The maximum volume that can be protected by the Firetrace CO₂ units is dependent on the minimum design concentration. The maximum volumes calculated from Table 8 for concentrations of 34% for Firetrace CO₂ systems are listed below.

Model	Volume (ft ³)
950504	Up to 70
951004	71 to 140
952004	141-300
953504	301-525
955004	526-700

Table 8: Maximum Protected Volume for IHP Systems

4.8.1 Example Calculations

The requirements given in Sections 4.1 through 4.8 describe the procedures to be used to design and size a Firetrace IHP CO₂ unit.

The following example provides guidelines, following procedures 4.2.a, through 4.2.e., in order to determine the quantity of CO₂ agent required and cylinder size for a total flooding application.

Example:

Given:

- Hazard – Small cabinet storing Ethyl Alcohol.
- Class B hazard
- Enclosure size: 4' wide x 4' long x 6' high. One (1) access door equipped with self closing apparatus
- Minimum anticipated ambient temperature: 50°F
- Maximum anticipated ambient temperature: 90°F

Procedure:

- a. Determine min. design concentration required (Refer to Table 5)
Use 43% min. design concentration for Ethyl Alcohol.
- b. Calculate hazard volume (V).
 $V = 4' \times 4' \times 6' = 96 \text{ Ft}^3$
- c. Calculate quantity (Q) of CO₂ required first using volume factor for 34% concentration (Refer to Table 7)
volume of 96 Ft³ shows that a Volume Factor 0.072 Lb CO₂/Ft³

$Q = 96 \text{ Ft}^3 \times 0.072 \text{ Lb CO}_2/\text{Ft}^3 = 6.912 \text{ Lbs. of CO}_2$ is required. Because this is based on a 34% concentration, it must be multiplied by the conversion factor, which can be found in Figure 2. For a design concentration of 43%, the conversion factor is 1.25.

$Q_{\text{total}} = 6.912 \times 1.25 = 8.64 \text{ Lbs}$ (This then requires the use of a IHP-1000 with 10 Lbs of CO₂)

4.9 Nozzle and Discharge Tubing Requirements

4.9.1 Discharge Nozzle Limitations

Nozzle P/N 500024 is to be used with all Firetrace IHP CO₂ extinguisher units in total flooding applications.

Nozzle P/N 510016 is to be used with all Firetrace IHP CO₂ extinguisher units in local applications.

Placement of nozzles shall be such that discharge of CO₂ will not splash flammable liquids or create dust clouds that could extend the fire.

More than one nozzle can be used to protect a particular hazard, as long as the "Equivalent Length of Pipe" for Firetrace IHP CO₂ systems is not exceeded. Refer to section 4.9.3 for information regarding the "Equivalent Length of Pipe".

4.9.2 Discharge Piping & Fitting Specifications

All Firetrace IHP Units shall use steel piping for the distribution system. The following piping and fittings shall be used or the Firetrace supplied 1/2 in. flexible discharge hoses.

Piping Specifications:

Material: Black or Galvanized steel pipe
Type: ASTM A 53 seamless or electric welded, Grade A or B
Size: 1/2 Pipe

Note: For other options consult NFPA 12 2018 Edition Section 4.7

Pipe Fitting Specifications:

Material: Malleable or ductile iron fittings
Type: Class 300

Part Number	Description
201825	2 ft High Pressure Flexible Hose 1/2" (MxM)
201826	4 ft High Pressure Flexible Hose 1/2" (MxM)
201827	6 ft High Pressure Flexible Hose 1/2" (MxM)
201828	8 ft High Pressure Flexible Hose 1/2" (MxM)
201829	10 ft High Pressure Flexible Hose 1/2" (MxM)

Table 9: Flexible Discharge Hose Specifications.

4.9.3 Maximum Piping and Fitting Limitations

The maximum "Equivalent Length of Piping" shall not exceed 24ft. The "Equivalent Length of Piping" includes individual lengths of pipe and all pipe fittings. Table 10 includes the equivalent lengths of 1/2 inch threaded pipe fittings that need to be considered when determining the total "Equivalent Length of Piping".

Pipe Size	Elbow Std. 45°	Elbow Std. 90°	Elbow 90° Long Radius & Tee Thru Flow	Tee Side	Union Coupling
1/2	0.8	1.7	1.0	3.4	0.4

Table 10: Equivalent length in feet of threaded pipe fittings.

4.10 Firetrace Detector Tubing

The Firetrace Detection Tubing (FDT) is a UL recognized component per UL standard 521. The Firetrace Detection Tubing is used as a combination linear heat detector and unit activation device to cause actuation of the Carbon Dioxide System. The tubing is installed throughout the hazard volume, with one end connected to the side of the cylinder valve.

Location and spacing of the tubing is critical to the response time in the event of a fire. The tubing should be placed above the hazard areas being protected. The Typical Tubing Placement diagram, located in Appendix B, provides general guidelines for placement of the detection tubing along with the maximum spacing and height limitations.

Depending on the configuration of specific hazards, the guidelines shown in the Typical Tubing Placement diagram may, or may not, be applicable. The maximum height that is allowed between layers is 3.28 feet (1 m), the maximum distance between passes is 21.12 inches (53.34 cm), and the maximum distance allowed from any wall to the tubing is 10.56 inches (26.82 cm). Refer to the Typical Tubing Placement diagram in Appendix A.

NOTE: It is recommended that the tubing not be placed horizontally adjacent to potential fire sources as this may significantly delay response time.

5.0 INSTALLATION INSTRUCTIONS

This section provides installation instructions covering components and limitations described in Sections 3 and 4 of this manual.

All components should be installed to facilitate proper inspection, testing, recharging, and any other required service or maintenance as may be necessary. Equipment must not be subjected to severe weather conditions or mechanical, chemical, or other damage, which could render the equipment inoperative. The equipment must be installed in accordance with instructions in this manual and NFPA 12.

WARNING

CO₂ cylinder/valve assemblies must be handled, installed, and serviced in accordance with the instruction contained in this manual and on the cylinder nameplate. Failure to follow these instructions could result in severe injury, property damage or death.

5.1 CO₂ Cylinder/Valve and Bracket Assemblies

The CO₂ cylinders should be located as close as possible to the protected enclosure. In some cases the cylinder can be mounted inside the protected enclosure. The assemblies shall be located in a readily accessible location to allow for ease of inspection service and maintenance. The cylinders shall be located in an environment protected from the weather and where the temperature range is between 0°F and + 130°F.

Cylinder and bracket must be mounted in the vertical plane with the cylinder valve facing up.

Mount the cylinder where it will not be subject to accidental damage or movement. Suitable protection must be installed where necessary to prevent damage or movement.

CAUTION

Make sure that the ball valve, located on the cylinder valve, is maintained in the “OFF” position, and the discharge port safety caps are in place. Failure to follow these instructions will result in actuation and discharge of the cylinder contents.

1. Securely mount the cylinder bracket to structural support using 2 or more mounting holes.
2. Secure cylinder in place using the bracket strap.

5.2 Discharge Piping and Nozzles

1. Locate the nozzle(s) following the guidelines and limitations described in Section 4.9.
2. Determine the routing of the discharge piping following the guidelines and limitations described in Section 4.9
3. Remove the safety cap from the valve discharge port as required. Attach female connection fittings (Firetrace P/N 200201) onto discharge port.
4. Install the necessary piping and fittings between the cylinder and nozzle(s). Secure piping with appropriate size piping clamps as required.

5.3 Firetrace Detection Tubing

CAUTION

1. Do not kink, bend, or crush Firetrace tubing in order to prevent leakage, which could result in accidental unit discharge.
2. Do not install tubing in a hazardous environment where the maximum ambient temperature exceeds 176°F (80°C)
3. Do not place the tubing on a surface where the temperature of the surface exceeds 140°F (60°C)
4. Maximum length of detector tubing shall not exceed 120 Feet.

1. Follow guidelines as outlined in section 4.10 and the drawing in Appendix A for the tubing placement.
2. Secure detection tubing using Mounting Tabs at 1.5 ft. intervals.
3. Use appropriate rubber/plastic grommets when detection tubing is routed through sharp holes in order to prevent damage to the tubing.
4. Cut the tube end, ensuring the cut is square, clean, and free from burrs. Check that no debris is left in the tube.
5. Thoroughly clean the tubing to a distance of at least 2 in. (5.08 cm) above the cut end, removing all dirt, grease, or grime. This will ensure a good seal inside the fitting.
6. Slide the tubing into the opening until it butts up against the inner wall. Pull lightly on the tubing and the brass outer ring should move outward slightly.
7. Ensure the FDT network is complete (all terminations present – a closed loop)
8. The detector tubing is now ready to be pressurized with nitrogen. (See section 5.4 for pressurization procedure)

5.4 Pressurization of Firetrace Detection Tubing

1. Attach the filling adapter (P/N 600023) to the detector-tubing end of line adapter.

2. Using a regulated dry nitrogen supply, pressurize the detection tubing with dry nitrogen through the filling adapter to 195 psig. It is recommended to have a portable dry nitrogen cylinder for on-site use.
3. Remove the filling adapter and attach calibrated test pressure gauge & O-ring to verify that the tubing is pressurized to at least 195 psig at 70°F.
4. With gauge still attached to the end of line adapter, test for leakage.
 - a. Apply soapy water solution to the cylinder valve connection, end of line adapter connection, and the pressure gauge connection. Observe for bubble leaks.
 - b. Wait 30 minutes, then observe pressure gauge. Any decrease in pressure is an indication of a leak.
 - c. In the event of a leak go back to Section 5.3 and repeat steps 4, 5, & 6.
 - d. If no leaks are observed proceed to step 5 of Section 5.4
5. If an optional pressure switch is to be installed in the EOL adapter, remove pressure gauge and install the washer and pressure switch using wiring instructions located on the device. Check pressure switch connection for bubble leaks using soapy water solution.
6. After confirming that there is no leakage within the detector tubing, **SLOWLY** rotate the ball valve lever counterclockwise to the “ON” position.

 CAUTION

If the ball valve lever is opened abruptly this may result in activation of the cylinder valve and unit discharge.

1. Tamper proof the unit by removing the ball valve lever completely and installing the ‘armed’ tamper proof (P/N 201132). Follow directions listed in Appendix A.
2. Ensure appropriate electrical connections to the optional EOL pressure switch, which can be used to notify unit discharge, shut down ventilation, etc., as may be required by the end user or the AHJ. (All electrical connections are to be in accordance to NFPA 70 National Electric Code)
3. Attach the warning nameplate(s) to the appropriate locations.
4. Unit is now fully armed and ready for use.

6.0 SERVICE, MAINTENANCE, & FILLING INSTRUCTIONS

 WARNING

1. CO₂ cylinder/valve assemblies must be handled, installed, inspected and serviced only by qualified and trained personnel in accordance with the instructions contained in this manual, the cylinder nameplate, NFPA 12, and any other regulations and codes that may apply.
2. Before performing maintenance or refilling procedures refer to the material safety data sheets in the appendix at the back of this manual.

6.1 General

A regular program of systematic maintenance must be established for continuous, proper operation of all CO₂ units, and to avoid violating the warranty. A periodic maintenance schedule must be followed and an inspection log maintained for ready reference. As a minimum, the log must record: (1) inspection interval, (2) inspection procedure performed, (3) maintenance performed, if any, as a result of inspection, and (4) name of inspector performing task.

6.2 Periodic Service and Maintenance

Perform service and maintenance of the CO₂ unit in accordance with the schedule shown in Table 11.

Schedule	Requirement	Reference Paragraph
Weekly	Visually inspect unit components	6.3.1
Monthly	Visually inspect unit components.	6.3.1
Semi-Annually	Check CO ₂ cylinder weight. Check nozzles for obstruction.	6.3.2
Every 5 Years	Perform external visual inspection of CO ₂ Cylinders.	6.3.3

Table 11: Periodic service and maintenance schedule.

6.3 Periodic Service and Maintenance Procedures

6.3.1 Weekly/Monthly Inspection

1. Make a general visual inspection of the CO₂ cylinder and equipment for damaged or missing parts.
2. Ensure access to hazard areas, discharge nozzles, and cylinders are unobstructed and that there are not obstructions to the operation of the equipment or distribution of CO₂ agent.
3. Inspect detection tubing in hazard area for abrasion, distortion, cuts, or dirt accumulation, and that there are no obstructions preventing tubing from sensing a fire should one occur.
4. Verify that there have been no changes in the size of the enclosure and that no new ventilation has been added.

6.3.2 Semi-Annual Inspection

1. Check CO₂ cylinder for weight.
2. Remove cylinder from the installation as follows:
 - a. Close ball valve, by turning ball valve lever clockwise to the "OFF" position.
 - b. Disconnect detector tubing at the ball valve. Note: There will be a loss of nitrogen pressure out of the tubing.
 - c. Disconnect piping and fittings from the cylinder valve discharge port.
 - d. Immediately install safety cap onto the valve discharge port.
 - e. Remove cylinder from bracket
3. Weigh cylinder. Compare measured weight with weight found on the cylinder nameplate. If the container shows a loss in agent quantity of more than 10 percent, the cylinder shall be refilled or replaced.
4. Remove nozzle(s) and inspect for obstructions. Reinstall nozzles.
5. Reinstall cylinder and re-pressurize detector tubing with nitrogen following the applicable procedures outlined in Section 5.0.

6.3.3 Five Year Inspection

CO₂ cylinders continuously in service without discharging shall be given a complete external visual inspection in place by a certified body. System hoses shall be tested every 5 years in accordance with NFPA 12.

6.4 Post Fire Maintenance

In the event of a unit discharge the following procedures shall be performed.

6.4.1 CO₂ Cylinder Valve

Remove the cylinder assembly from the installation following procedures detailed in Section 6.3.2, Step 2. Inspect and service the CO₂ cylinder valve as follows:

WARNING

Prior to removal of the valve from the cylinder, verify that all pressure has been released. To relieve any remaining pressure loosen but do not remove the valve safety caps. Then open the ball valve to the “ON” position and allow any residual pressure to leak out past the plugs.

1. Only after verifying that the cylinder has been depressurized, remove valve from cylinder.
2. Perform a visual inspection of the valve to verify that no damage occurred due to the fire. If integrity of the valve looks compromised, contact Firetrace. The valve should not be serviced by anyone other than a Firetrace Technician.
3. Change the cylinder/valve o-ring. Discharge of CO₂ causes the o-ring to undergo vacuum decompression; failure to change the o-ring will result in leaks around the cylinder/valve connection.
4. Re-seat the piston in the valve by following the procedure in Section 6.6, Step 2.

6.5 CO₂ Cylinder Retest

Firetrace CO₂ cylinders are built to DOT-3AL specifications and therefore fall under DOT regulations for retest prior to refill. DOT-3AL cylinders used exclusively in CO₂ service are required to be hydrostatically retested and re-stamped prior to recharge and shipment if the last retest date has expired.

- The IHP Cylinder shall be subject to a hydrostatic pressure test at intervals specified in CFR Title 49 (from date stamped on cylinder).
- Carefully depressurize the system following the procedures in Section 6.3.2 & 6.4.1.

WARNING

DO NOT assume that IHP cylinders have been completely discharged or are empty after a suspected or verified discharge event. Any remaining pressure in the system could be still considered extremely hazardous and if not handled properly can cause property damage, bodily injury, or death. Never handle the systems by the pressure switches or ball valve. Always wear safety glasses and make sure the discharge port safety plug(s) and cap(s) are properly in place before system installation, servicing, or other general handling.

Firetrace CO₂ (DOT-3AL) containers requiring retest must be hydrostatically tested in accordance with DOT CFR Title 49, General requirements for requalification of specification cylinders section & Requirements for requalification of specification cylinders section. This periodic retest must be performed by an authorized retester having a current identification number issued by the Associated Administrator for Hazardous Material Safety of DOT, and must include an internal and external examination in accordance with CGA pamphlet C-6, C-6.1, C-6.2, or C-6.3, as applicable. The test procedures are described in CGA pamphlet C-1. Because volumetric expansion of the container must be measured, only the water jacket volumetric expansion method or the direct expansion methods are acceptable.

Retest can be performed by either of the following methods:

CFR Title 49 > Subtitle B (Other Regulations Relating to Transportation) > **Chapter I** (Pipeline and Hazardous Materials Safety Administration, Department of Transportation) > **Subchapter C** (Hazardous Materials Regulations) > Continuing Qualification and Maintenance of Packagings) > **Part 180** (Qualification, Maintenance and Use of Cylinders) > General requirements for requalification of specification cylinders & Requirements for requalification of specification cylinders

Retest Method	Due (Yrs)
External visual inspection	5
Full hydrostatic test including determination of cylinder expansion.	12

Table 12: Testing Intervals

Please note that testing intervals specified by CFR are subject to change without notice. Refer to the provided link for the most current requirements. (<https://www.ecfr.gov/current/title-49>)

6.6 Filling Procedures

1. Weigh and record cylinder empty weight with valve and the 2 safety caps installed.
2. Remove the safety cap from the discharge port and visually check that the piston is seated inside of the valve. Replace safety cap. (If piston is not seated, apply 250 psi of Nitrogen pressure through the ball valve. You will be able to hear the piston change positions. Return ball valve to "OFF" position and remove hose connection).
3. Remove safety cap from filling port and attach Firetrace CO₂ filling adapter (P/N 600024) to filling port
4. Attach CO₂ supply line to filling adapter. (CO₂ is to be pumped)
5. Place the cylinder, with supply line hooked up, on scale and zero the scale. Open the supply of CO₂ from bulk tank to fill the cylinder to the required weight.
6. Close supply of CO₂ while maintaining all connections.
7. Disconnect CO₂ recharge adapter and immediately attach discharge port cap to valve.

CAUTION

Any hissing or discharge coming from vent valve indicates that the piston is not seating properly or has opened. If this occurs, repeat Step 10 and verify that the cylinder valve piston remains closed.

1. Verify weight by checking it against what is printed on the label.
2. Leak test the cylinder.
3. Cylinder is now ready to be transported to the installation site.

Note: All reasonable efforts must be made to prevent emitting any CO₂ to the environment during filling or servicing of Firetrace units.

APPENDIX A

COMPONENT DESCRIPTION


EXAMPLES

Parts List

5, 10, & 20 LB. PRE-ENGINEERED AUTOMATIC INDIRECT CO₂ EXTINGUISHER UNIT


950504 5 LB. CO₂ IHP
951004 10 LB. CO₂ IHP
952004 20 LB. CO₂ IHP
953504 35 LB. CO₂ IHP
955004 50 LB. CO₂ IHP

ITEM	PART NO.	DESCRIPTION	SYSTEM
1	310201	IHP Valve	All Systems
2	110050	5 Lb. Cylinder	5 LB
2	110100	10 Lb. Cylinder	10 LB
2	110200	20 Lb. Cylinder	20 LB
2	110350	35 Lb. Cylinder	35 LB
2	110500	50 Lb. Cylinder	50 LB
3	600008	Siphon Tube	5 LB
3	600005	Siphon Tube	10 LB
3	600006	Siphon Tube	20 LB
3	600035	Siphon Tube	35 LB
3	600036	Siphon Tube	50 LB
4	111201	5 Lb. Heavy Duty Bracket	5 LB
4	111010	10 Lb. Heavy Duty Bracket	10 LB
4	111020	20 Lb. Heavy Duty Bracket	20 LB
4	111035	Strap Bracket	35, 50 LB
5	310310	Discharge Port Safety Cap	All Systems
6	310305	Collar O-Ring	All Systems
7	200179	Slip-On Union	All Systems
8	600053	Pull Pin	All Systems
9	600007	Nameplate: CO ₂	All Systems
*	800100	Warranty/Registration Card	All Systems
*	200201	Discharge Port Adapter	All Systems
* PART NOT PICTURED			






Discharge Line Parts List

ITEM NUMBER	PART NUMBER	DESCRIPTION
1	500024	Total Flooding Nozzle
2	510016	IHP Narrow Dispersion Nozzle
*	850028	Fitting - Hose to Hose 1/2" HP (FxF)
*	850029	Fitting - Hose to Hose Elbow 1/2" HP (FxF)
*	850030	Fitting - Hose to Hose Tee 1/2" HP (FxFxF)
*	850031	Fitting - Fitting to Nozzle Bulkhead 1/2" HP (MxM)
3	850036	Fitting - Swivel Adapter 1/2" HP (MxF)
4	200201	IHP Discharge Port Adapter
*	201825	2 ft High Pressure Flexible Hose 1/2" (MxM)
*	201826	4 ft High Pressure Flexible Hose 1/2" (MxM)
*	201827	6 ft High Pressure Flexible Hose 1/2" (MxM)
*	201828	8 ft High Pressure Flexible Hose 1/2" (MxM)
*	201829	10 ft High Pressure Flexible Hose 1/2" (MxM)
* PART NOT PICTURED		




Detection Line Parts List

ITEM NUMBER	PART NUMBER	DESCRIPTION
*	200005	Firetrace Detection/Actuation Tubing (by the foot)
*	200158	Tube Union Slip On Fitting
1	200157	Tube Tee Slip On Fitting
2	200178	Tube Elbow Slip On Fitting
*	200179	Tube to Threads Union Slip On Fitting
*	200177	Tube to Threads Tee Slip On Fitting
*	200159	Tube to Threads Elbow Slip On Fitting
*	200133	Tube Plug
3	600064	Manual Release With CO ₂ Gauge and Slip On Fitting
*	200168	End Of Line Adapter With Slip On Fitting
*	200169	In Line Adapter With Slip On Fitting
*	310303	Plug With O-Ring For End Of Line Adapter
*	400029	CO ₂ 195 psi Pressure Gauge
*	400004	Pressure Switch With Washer for End Of Line Adapter
*	600090	Audible Alarm (Battery Operated)
*	200171	Mounting Tabs (Qty. 12)
*	200150	Rubber Grommets (Qty. 2)
*	200151	Plastic Grommets (Qty. 2)
* PART NOT PICTURED		



Firetrace Indirect High Pressure (IHP) Valve P/N 310201

Note: Do not dispose of Discharge & Fill Port Caps



Tamper Proof (Armed) Instruction (P/N 201132)




Figure 3 – Tamper Proof (Armed) Assembly

1. Verify that the ball lever is in the “ON” position
2. Remove the lever
3. Install the sleeve (as pictured above)
4. Apply the plastic/metal tie wrap and record the serial number stamped on the wrap.

Tamper Proof (Disarmed) Instruction (P/N 201137)





Figure 4 - Tamper Proof (Disarmed) Assembly

1. Verify that the ball lever is in the “OFF” position
2. Remove the lever
3. Install the sleeve (as pictured above)
4. Apply the plastic/metal tie wrap and record the serial number stamped on the wrap.


Firetrace Tubing Placement Diagram



MAXIMUM HEIGHT TUBING LAYOUT

Side View

TUBING PLACED AT
3.28ft (1m) HIGH
INTERVALS



MAXIMUM AREA TUBING LAYOUT

Overhead View

Maximum Length: 120ft
Maximum Height Between Layers: 3.28ft
Maximum Distance Between Passes: 21.12in

APPENDIX B

Material Safety Data Sheet

Carbon dioxide

Safety Data Sheet P-4574

This SDS conforms to U.S. Code of Federal Regulations 29 CFR 1910.1200, Hazard Communication.
Date of issue: 01/01/1980 Revision date: 10/17/2016 Supersedes: 07/19/2016

SECTION 1: Product and company identification	
1.1. Product identifier	
Product form	: Substance
Name	: Carbon dioxide
CAS No	: 124-38-9
Formula	: CO ₂
Other means of identification	: Medipure® Carbon Dioxide, Extendapak® EX-2, Refrigerant gas R744, carbonic anhydride, carbonic acid gas
1.2. Relevant identified uses of the substance or mixture and uses advised against	
Use of the substance/mixture	: Industrial use. Use as directed.
1.3. Details of the supplier of the safety data sheet	
	Praxair, Inc. 10 Riverview Drive Danbury, CT 06810-6268 - USA T 1-800-772-9247 (1-800-PRAXAIR) - F 1-716-879-2146 www.praxair.com
1.4. Emergency telephone number	
Emergency number	: Onsite Emergency: 1-800-645-4633 CHEMTREC, 24hr/day 7days/week — Within USA: 1-800-424-6300, Outside USA: 001-703-527-3887 (collect calls accepted, Contract 17729)
SECTION 2: Hazard identification	
2.1. Classification of the substance or mixture	
GHS-US classification	
Liquefied gas H280	
2.2. Label elements	
GHS-US labeling	
Hazard pictograms (GHS-US)	:  GHS04
Signal word (GHS-US)	: WARNING
Hazard statements (GHS-US)	: H280 - CONTAINS GAS UNDER PRESSURE; MAY EXPLODE IF HEATED OSHA-H01 - MAY DISPLACE OXYGEN AND CAUSE RAPID SUFFOCATION CGA-HG01 - MAY CAUSE FROSTBITE CGA-HG03 - MAY INCREASE RESPIRATION AND HEART RATE
Precautionary statements (GHS-US)	: P202 - Do not handle until all safety precautions have been read and understood P281 - Avoid breathing gas P282 - Do not get in eyes, on skin, or on clothing P271+P403 - Use and store only outdoors or in a well-ventilated place CGA-PG05 - Use a back flow preventive device in the piping CGA-PG10 - Use only with equipment rated for cylinder pressure CGA-PG06 - Close valve after each use and when empty CGA-PG02 - Protect from sunlight when ambient temperature exceeds 52°C (125°F)
EN (English US)	SDS ID: P-4574 1/9

This document is only controlled while on the Praxair, Inc. website and a copy of this controlled version is available for download. Praxair cannot assure the integrity or accuracy of any version of this document after it has been downloaded or removed from our website.

Carbon dioxide

Safety Data Sheet P-4574

This SDS conforms to U.S. Code of Federal Regulations 29 CFR 1910.1200, Hazard Communication.
Date of issue: 01/01/1980 Revision date: 10/17/2016 Supersedes: 07/19/2016

2.3. Other hazards

Other hazards not contributing to the classification

: Asphyxiant in high concentrations

Contact with liquid may cause cold burns/frostbite

WARNING: Concentration levels of carbon dioxide above about 1 percent are dangerous. Praxair recommends continuous monitoring with alarms to indicate unsafe conditions before and during potential personnel exposure. Use appropriate monitoring devices to ensure a safe oxygen level (minimum of 19.5 percent) and a safe carbon dioxide level.

2.4. Unknown acute toxicity (GHS US)

No data available

SECTION 3: Composition/Information on ingredients

3.1. Substance

Name : Carbon dioxide

CAS No : 124-38-9

Name	Product identifier	%
Carbon dioxide	(CAS No) 124-38-9	99.5 - 100

3.2. Mixture

Not applicable

SECTION 4: First aid measures

4.1. Description of first aid measures

First-aid measures after inhalation

: Remove to fresh air and keep at rest in a position comfortable for breathing. If not breathing, give artificial respiration, with supplemental oxygen given by qualified personnel. If breathing is difficult, qualified personnel should give oxygen. Call a physician.

First-aid measures after skin contact

: MAY CAUSE FROSTBITE. For exposure to liquid, cold vapor, or solid carbon dioxide (dry ice), immediately warm frostbite area with warm water not to exceed 41°C (105°F). Water temperature should be tolerable to normal skin. Maintain skin warming for at least 15 minutes or until normal coloring and sensation have returned to the affected area. In case of massive exposure, remove clothing while showering with warm water. Seek medical evaluation and treatment as soon as possible.

First-aid measures after eye contact

: Immediately flush eyes thoroughly with water for at least 15 minutes. Hold the eyelids open and away from the eyeballs to ensure that all surfaces are flushed thoroughly. Contact an ophthalmologist immediately.

First-aid measures after ingestion

: Ingestion is not considered a potential route of exposure.

4.2. Most important symptoms and effects, both acute and delayed

No additional information available

4.3. Indication of any immediate medical attention and special treatment needed

None.

SECTION 5: Firefighting measures

5.1. Extinguishing media

Suitable extinguishing media : Use extinguishing media appropriate for surrounding fire.

5.2. Special hazards arising from the substance or mixture

Explosion hazard

: Heat of fire can build pressure in container and cause it to rupture. Containers are equipped with a pressure relief device. (Exceptions may exist where authorized by DOT.) No part of the container should be subjected to a temperature higher than 125°F (52°C).

Reactivity

: No reactivity hazard other than the effects described in sub-sections below.

Carbon dioxide

Safety Data Sheet P-4574

This SDS conforms to U.S. Code of Federal Regulations 29 CFR 1910.1200, Hazard Communication.
Date of issue: 01/01/1980 Revision date: 10/17/2016 Supersedes: 07/19/2016

5.3. Advice for firefighters	
Firefighting instructions	: WARNING! Liquid and gas under pressure. Evacuate all personnel from the danger area. Use self-contained breathing apparatus (SCBA) and protective clothing. Immediately cool containers with water from maximum distance. Stop flow of gas if safe to do so, while continuing cooling water spray. Remove ignition sources if safe to do so. Remove containers from area of fire if safe to do so. On-site fire brigades must comply with OSHA 29 CFR 1910.156 and applicable standards under 29 CFR 1910 Subpart L—Fire Protection.
Other information	: Containers are equipped with a pressure relief device. (Exceptions may exist where authorized by DOT [U.S.] or TC [Canada].).

SECTION 6: Accidental release measures

6.1. Personal precautions, protective equipment and emergency procedures	
General measures	: WARNING! Liquid and gas under pressure.. Rapid release of gaseous carbon dioxide through a pressure relief device (PRD) or valve can result in the formation of dry ice, which is very cold and can cause frostbite..
6.1.1. For non-emergency personnel	No additional information available
6.1.2. For emergency responders	No additional information available
6.2. Environmental precautions	
	Try to stop release.
6.3. Methods and material for containment and cleaning up	
For containment	: Prevent waste from contaminating the surrounding environment. Discard any product, residue, disposable container, or liner in an environmentally acceptable manner, in full compliance with federal, provincial, and local regulations. If necessary, call your local supplier for assistance.
6.4. Reference to other sections	
	See also sections 8 and 13.

SECTION 7: Handling and storage

7.1. Precautions for safe handling	
Precautions for safe handling	: Avoid breathing gas Do not get in eyes, on skin, or on clothing This gas is heavier than air and in an enclosed space tends to accumulate near the floor, displacing air and pushing it upward. This creates an oxygen-deficient atmosphere near the floor. Ventilate space before entry. Verify sufficient oxygen concentration WARNING: Concentration levels of carbon dioxide above about 1 percent are dangerous. Praxair recommends continuous monitoring with alarms to indicate unsafe conditions before and during potential personnel exposure. Use appropriate monitoring devices to ensure a safe oxygen level (minimum of 19.5 percent) and a safe carbon dioxide level Wear leather safety gloves and safety shoes when handling cylinders. Protect cylinders from physical damage; do not drag, roll, slide or drop. While moving cylinder, always keep in place removable valve cover. Never attempt to lift a cylinder by its cap; the cap is intended solely to protect the valve. When moving cylinders, even for short distances, use a cart (trolley, hand truck, etc.) designed to transport cylinders. Never insert an object (e.g. wrench, screwdriver, pry bar) into cap openings; doing so may damage the valve and cause a leak. Use an adjustable strap wrench to remove over-tight or rusted caps. Slowly open the valve. If the valve is hard to open, discontinue use and contact your supplier. Close the container valve after each use; keep closed even when empty. Never apply flame or localized heat directly to any part of the container. High temperatures may damage the container and could cause the pressure relief device to fail prematurely, venting the container contents. For other precautions in using this product, see section 16.

Carbon dioxide

Safety Data Sheet P-4574

This SDS conforms to U.S. Code of Federal Regulations 29 CFR 1910.1200, Hazard Communication.
Date of issue: 01/01/1980 Revision date: 10/17/2016 Supersedes: 07/19/2016

7.2. Conditions for safe storage, including any incompatibilities

- Storage conditions**
- Store in a cool, well-ventilated place. Store and use with adequate ventilation. Store only where temperature will not exceed 125°F (52°C). Firmly secure containers upright to keep them from falling or being knocked over. Install valve protection cap, if provided, firmly in place by hand. Store full and empty containers separately. Use a first-in, first-out inventory system to prevent storing full containers for long periods.
 - This gas is heavier than air and in an enclosed space tends to accumulate near the floor, displacing air and pushing it upward. This creates an oxygen-deficient atmosphere near the floor. Ventilate space before entry. Verify sufficient oxygen concentration.

7.3. Specific end use(s)

None.

SECTION 8: Exposure controls/personal protection

8.1. Control parameters

Carbon dioxide (124-38-9)		
ACGIH	ACGIH TLV-TWA (ppm)	5000 ppm
ACGIH	ACGIH TLV-STEL (ppm)	30000 ppm
USA OSHA	OSHA PEL (TWA) (mg/m³)	9000 mg/m³
USA OSHA	OSHA PEL (TWA) (ppm)	5000 ppm
USA IDLH	US IDLH (ppm)	40000 ppm
ACGIH	Not established	
USA OSHA	Not established	
Carbon dioxide (124-38-9)		
ACGIH	ACGIH TLV-TWA (ppm)	5000 ppm
ACGIH	ACGIH TLV-STEL (ppm)	30000 ppm
USA OSHA	OSHA PEL (TWA) (mg/m³)	9000 mg/m³
USA OSHA	OSHA PEL (TWA) (ppm)	5000 ppm

8.2. Exposure controls

- Appropriate engineering controls**
- Use a local exhaust system with sufficient flow velocity to maintain an adequate supply of air in the worker's breathing zone. Mechanical (general): General exhaust ventilation may be acceptable if it can maintain an adequate supply of air. **WARNING:** Concentration levels of carbon dioxide above about 1 percent are dangerous. Praxair recommends continuous monitoring with alarms to indicate unsafe conditions before and during potential personnel exposure. Use appropriate monitoring devices to ensure a safe oxygen level (minimum of 19.5 percent) and a safe carbon dioxide level.
- Materials for protective clothing**
- Wear work gloves and metatarsal shoes for cylinder handling. Protective equipment where needed. Select in accordance with OSHA 29 CFR 1910.132, 1910.136, and 1910.138.
- Eye protection**
- Wear safety glasses when handling cylinders; vapor-proof goggles and a face shield during cylinder changeout or whenever contact with product is possible. Select eye protection in accordance with OSHA 29 CFR 1910.133.
- Skin and body protection**
- As needed for welding, wear hand, head, and body protection to help prevent injury from radiation and sparks. (See ANSI Z49.1.) At a minimum, this includes welder's gloves and protective goggles, and may include arm protectors, aprons, hats, and shoulder protection as well as substantial clothing.
- Respiratory protection**
- When workplace conditions warrant respirator use, follow a respiratory protection program that meets OSHA 29 CFR 1910.134, ANSI Z88.2, or MSHA 30 CFR 72.710 (where applicable). Use an air-supplied or air-purifying cartridge if the action level is exceeded. Ensure that the respirator has the appropriate protection factor for the exposure level. If cartridge type respirators are used, the cartridge must be appropriate for the chemical exposure. For emergencies or instances with unknown exposure levels, use a self-contained breathing apparatus (SCBA).
- Thermal hazard protection**
- Wear cold insulating gloves when transfilling or breaking transfer connections.

Carbon dioxide

Safety Data Sheet P-4574

This SDS conforms to U.S. Code of Federal Regulations 29 CFR 1910.1200, Hazard Communication.
 Date of issue: 01/01/1980 Revision date: 10/17/2016 Supersedes: 07/19/2016

SECTION 9: Physical and chemical properties

9.1. Information on basic physical and chemical properties

Physical state	: Gas
Appearance	: Colorless gas.
Molecular mass	: 44 g/mol
Color	: Colorless.
Odor	: Odorless.
Odor threshold	: No data available
pH	: 3.7 (carbonic acid)
Relative evaporation rate (butyl acetate=1)	: No data available
Relative evaporation rate (ether=1)	: Not applicable.
Melting point	: No data available
Freezing point	: No data available
Boiling point	: -78.5 °C (-109.3°F)
Flash point	: No data available
Critical temperature	: 31 °C (87.7°F)
Auto-ignition temperature	: No data available
Decomposition temperature	: No data available
Flammability (solid, gas)	: No data available
Vapor pressure	: 57.3 bar (831 psig)
Critical pressure	: 73.7 bar (1069 psig)
Relative vapor density at 20 °C	: 762
Relative density	: 1.22
Relative gas density	: 1.52
Solubility	: Water: 2000 mg/l Completely soluble.
Log Pow	: 0.83
Log Kow	: Not applicable.
Viscosity, kinematic	: Not applicable.
Viscosity, dynamic	: Not applicable.
Explosive properties	: Not applicable.
Oxidizing properties	: None.
Explosion limits	: No data available

9.2. Other information

Gas group	: Liquefied gas
Additional information	: Gas/vapor heavier than air. May accumulate in confined spaces, particularly at or below ground level

SECTION 10: Stability and reactivity

10.1. Reactivity

No reactivity hazard other than the effects described in sub-sections below.

10.2. Chemical stability

Stable under normal conditions.

10.3. Possibility of hazardous reactions

None.

10.4. Conditions to avoid

None under recommended storage and handling conditions (see section 7).

10.5. Incompatible materials

Alkali metals, Alkaline earth metals, Acetylide forming metals, Chromium, Titanium > 1022°F (550°C), Uranium (U) > 1382°F (750°C), Magnesium > 1427°F (775°C).

EN (English US)

SDS ID: P-4574

5/9

This document is only controlled while on the Praxair, Inc. website and a copy of this controlled version is available for download. Praxair cannot assure the integrity or accuracy of any version of this document after it has been downloaded or removed from our website.

Carbon dioxide

Safety Data Sheet P-4574

This SDS conforms to U.S. Code of Federal Regulations 29 CFR 1910.1200, Hazard Communication.
Date of issue: 01/01/1980 Revision date: 10/17/2016 Supersedes: 07/19/2016

10.6. Hazardous decomposition products

Electrical discharges and high temperatures decompose carbon dioxide into carbon monoxide and oxygen. The welding process may generate hazardous fumes and gases.

SECTION 11: Toxicological information

11.1. Information on toxicological effects

Acute toxicity	: Not classified
Skin corrosion/irritation	: Not classified
	pH: 3.7 (carbonic acid)
Serious eye damage/irritation	: Not classified
	pH: 3.7 (carbonic acid)
Respiratory or skin sensitization	: Not classified
Germ cell mutagenicity	: Not classified
Carcinogenicity	: Not classified
Reproductive toxicity	: Not classified
Specific target organ toxicity (single exposure)	: Not classified
Specific target organ toxicity (repeated exposure)	: Not classified
Aspiration hazard	: Not classified

SECTION 12: Ecological information

12.1. Toxicity

Ecology - general : No ecological damage caused by this product.

12.2. Persistence and degradability

Carbon dioxide (124-38-9)	
Persistence and degradability	No ecological damage caused by this product.
Carbon dioxide (124-38-9)	
Persistence and degradability	No ecological damage caused by this product.

12.3. Bioaccumulative potential

Carbon dioxide (124-38-9)	
BCF fish 1	(no bioaccumulation)
Log Pow	0.83
Log Kow	Not applicable.
Bioaccumulative potential	No ecological damage caused by this product.
Carbon dioxide (124-38-9)	
BCF fish 1	(no bioaccumulation)
Log Pow	0.83
Log Kow	Not applicable.
Bioaccumulative potential	No ecological damage caused by this product.

12.4. Mobility in soil

Carbon dioxide (124-38-9)	
Mobility in soil	No data available.
Ecology - soil	No ecological damage caused by this product.
Carbon dioxide (124-38-9)	
Mobility in soil	No data available.
Ecology - soil	No ecological damage caused by this product.

Carbon dioxide Safety Data Sheet P-4574

This SDS conforms to U.S. Code of Federal Regulations 29 CFR 1910.1200, Hazard Communication.
Date of issue: 01/01/1980 Revision date: 10/17/2016 Supersedes: 07/19/2016

12.5. Other adverse effects

Effect on ozone layer : None
Global warming potential [CO2=1] : 1
Effect on the global warming : When discharged in large quantities may contribute to the greenhouse effect

SECTION 13: Disposal considerations

13.1. Waste treatment methods

Waste treatment methods : May be vented to atmosphere in a well ventilated place. Discharge to atmosphere in large quantities should be avoided. Do not discharge into any place where its accumulation could be dangerous. Contact supplier if guidance is required.
Waste disposal recommendations : Do not attempt to dispose of residual or unused quantities. Return container to supplier.

SECTION 14: Transport information

In accordance with DOT

Transport document description : UN1013 Carbon dioxide, 2.2
UN-No.(DOT) : UN1013
Proper Shipping Name (DOT) : Carbon dioxide
Class (DOT) : 2.2 - Class 2.2 - Non-flammable compressed gas 49 CFR 173.115
Hazard labels (DOT) : 2.2 - Non-flammable gas



Additional information

Emergency Response Guide (ERG) Number : 120
Other information : No supplementary information available.
Special transport precautions : Avoid transport on vehicles where the load space is not separated from the driver's compartment. Ensure vehicle driver is aware of the potential hazards of the load and knows what to do in the event of an accident or an emergency. Before transporting product containers:
- Ensure there is adequate ventilation. - Ensure that containers are firmly secured. - Ensure cylinder valve is closed and not leaking. - Ensure valve outlet cap nut or plug (where provided) is correctly fitted. - Ensure valve protection device (where provided) is correctly fitted.

Transport by sea

UN-No. (IMDG) : 1013
Proper Shipping Name (IMDG) : CARBON DIOXIDE
Class (IMDG) : 2 - Gases
MFAG-No : 120

Air transport

UN-No. (IATA) : 1013
Proper Shipping Name (IATA) : Carbon dioxide
Class (IATA) : 2
Civil Aeronautics Law : Gases under pressure/Gases nonflammable nontoxic under pressure

SECTION 15: Regulatory information

15.1. US Federal regulations

Carbon dioxide (124-38-9)	
Listed on the United States TSCA (Toxic Substances Control Act) inventory	
SARA Section 311/312 Hazard Classes	Immediate (acute) health hazard Sudden release of pressure hazard

EN (English US)

SDS ID: P-4574

7/9

This document is only controlled while on the Praxair, Inc. website and a copy of this controlled version is available for download. Praxair cannot assure the integrity or accuracy of any version of this document after it has been downloaded or removed from our website.

Carbon dioxide

Safety Data Sheet P-4574

This SDS conforms to U.S. Code of Federal Regulations 29 CFR 1910.1200, Hazard Communication.
Date of issue: 01/01/1980 Revision date: 10/17/2016 Supersedes: 07/19/2016

15.2. International regulations

CANADA

Carbon dioxide (124-38-9)
Listed on the Canadian DSL (Domestic Substances List)
Carbon dioxide (124-38-9)
Listed on the Canadian DSL (Domestic Substances List)

EU-Regulations

Carbon dioxide (124-38-9)
Listed on the EEC inventory EINECS (European Inventory of Existing Commercial Chemical Substances)

15.2.2. National regulations

Carbon dioxide (124-38-9)
Listed on the AICS (Australian Inventory of Chemical Substances)
Listed on IECSC (Inventory of Existing Chemical Substances Produced or Imported in China)
Listed on the Japanese ENCS (Existing & New Chemical Substances) inventory
Listed on the Korean ECL (Existing Chemicals List)
Listed on NZIoC (New Zealand Inventory of Chemicals)
Listed on PICCS (Philippines Inventory of Chemicals and Chemical Substances)
Listed on the Canadian IDL (Ingredient Disclosure List)
Listed on INSQ (Mexican National Inventory of Chemical Substances)
Listed on CICR (Turkish Inventory and Control of Chemicals)

15.3. US State regulations

Carbon dioxide(124-38-9)	
U.S. - California - Proposition 65 - Carcinogens List	No
U.S. - California - Proposition 65 - Developmental Toxicity	No
U.S. - California - Proposition 65 - Reproductive Toxicity - Female	No
U.S. - California - Proposition 65 - Reproductive Toxicity - Male	No
State or local regulations	U.S. - Massachusetts - Right To Know List U.S. - New Jersey - Right to Know Hazardous Substance List U.S. - Pennsylvania - RTK (Right to Know) List

Carbon dioxide (124-38-9)				
U.S. - California - Proposition 65 - Carcinogens List	U.S. - California - Proposition 65 - Developmental Toxicity	U.S. - California - Proposition 65 - Reproductive Toxicity - Female	U.S. - California - Proposition 65 - Reproductive Toxicity - Male	Non-significant risk level (NSRL)
No	No	No	No	

Carbon dioxide (124-38-9)
U.S. - Massachusetts - Right To Know List
U.S. - New Jersey - Right to Know Hazardous Substance List
U.S. - Pennsylvania - RTK (Right to Know) List

Carbon dioxide

Safety Data Sheet P-4574

This SDS conforms to U.S. Code of Federal Regulations 29 CFR 1910.1200, Hazard Communication.
Date of issue: 01/01/1980 Revision date: 10/17/2016 Supersedes: 07/19/2016

SECTION 16: Other information

Other information

: When you mix two or more chemicals, you can create additional, unexpected hazards. Obtain and evaluate the safety information for each component before you produce the mixture. Consult an industrial hygienist or other trained person when you evaluate the end product. Before using any plastics, confirm their compatibility with this product.

Fumes and gases produced during welding and cutting processes can be dangerous to your health and may cause serious lung disease. **KEEP YOUR HEAD OUT OF FUMES. DO NOT BREATHE FUMES AND GASES.** Use enough ventilation, local exhaust, or both to keep fumes and gases from your breathing zone and the general area. Short-term overexposure to fumes may cause dizziness, nausea, and dryness or irritation of the nose, throat, and eyes; or may cause other similar discomfort. Contaminants in the air may add to the hazard of fumes and gases. One such contaminant, chlorinated hydrocarbon vapors from cleaning and degreasing activities, poses a special risk. **DO NOT USE ELECTRIC ARCS IN THE PRESENCE OF CHLORINATED HYDROCARBON VAPORS—HIGHLY TOXIC PHOSGENE MAY BE PRODUCED.** Metal coatings such as paint, plating, or galvanizing may generate harmful fumes when heated. Residues from cleaning materials may also be harmful. **AVOID ARC OPERATIONS ON PARTS WITH PHOSPHATE RESIDUES (ANTI-RUST, CLEANING PREPARATIONS)—HIGHLY TOXIC PHOSPHINE MAY BE PRODUCED.**

The opinions expressed herein are those of qualified experts within Praxair, Inc. We believe that the information contained herein is current as of the date of this Safety Data Sheet. Since the use of this information and the conditions of use are not within the control of Praxair, Inc, it is the user's obligation to determine the conditions of safe use of the product.

Praxair SDSs are furnished on sale or delivery by Praxair or the independent distributors and suppliers who package and sell our products. To obtain current SDSs for these products, contact your Praxair sales representative, local distributor, or supplier, or download from www.praxair.com. If you have questions regarding Praxair SDSs, would like the document number and date of the latest SDS, or would like the names of the Praxair suppliers in your area, phone or write the Praxair Call Center (Phone: 1-800-PRAXAIR/1-800-772-9247; Address: Praxair Call Center, Praxair, Inc, P.O. Box 44, Tonawanda, NY 14151-0044).

Praxair asks users of this product to study this SDS and become aware of the product hazards and safety information. To promote safe use of this product, a user should (1) notify employees, agents, and contractors of the information in this SDS and of any other known product hazards and safety information, (2) furnish this information to each purchaser of the product, and (3) ask each purchaser to notify its employees and customers of the product hazards and safety information.

PRAXAIR, the Flowing Airstream design, Medipure, and the Medipure design are trademarks or registered trademarks of Praxair Technology, Inc. in the United States and/or other countries.

NFPA health hazard

: 2 - Intense or continued exposure could cause temporary incapacitation or possible residual injury unless prompt medical attention is given.

NFPA fire hazard


: 0 - Materials that will not burn.

NFPA reactivity

: 0 - Normally stable, even under fire exposure conditions, and are not reactive with water.

NFPA specific hazard

: SA - This denotes gases which are simple asphyxiants.



HMIS III Rating

Health

: 1 Slight Hazard - Irritation or minor reversible injury possible

Flammability

: 0 Minimal Hazard

Physical

: 3 Serious Hazard

SDS US (GHS HazCom 2012) - Praxair

This information is based on our current knowledge and is intended to describe the product for the purposes of health, safety and environmental requirements only. It should not therefore be construed as guaranteeing any specific property of the product.

EN (English US)

SDS ID: P-4574

9/9

This document is only controlled while on the Praxair, Inc. website and a copy of this controlled version is available for download. Praxair cannot assure the integrity or accuracy of any version of this document after it has been downloaded or removed from our website.